



ESP8266 SDK API Guide

Version 1.2.0

Espressif Systems IOT Team

Copyright (c) 2015



Disclaimer and Copyright Notice

Information in this document, including URL references, is subject to change without notice.

THIS DOCUMENT IS PROVIDED AS IS WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, NONINFRINGEMENT, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION OR SAMPLE. All liability, including liability for infringement of any proprietary rights, relating to use of information in this document is disclaimed. No licenses express or implied, by estoppel or otherwise, to any intellectual property rights are granted herein.

The Wi-Fi Alliance Member Logo is a trademark of the Wi-Fi Alliance.

All trade names, trademarks and registered trademarks mentioned in this document are property of their respective owners, and are hereby acknowledged.

Copyright © 2015 Espressif Systems Inc. All rights reserved.



Table of Content

1. Preambles	13
2. Overview.....	14
3. Application Programming Interface (APIs).....	15
3.1. Software Timer	15
1. os_timer_arm.....	15
2. os_timer_disarm	16
3. os_timer_setfn	16
4. system_timer_reinit	16
5. os_timer_arm_us	17
3.2. Hardware Timer	17
1. hw_timer_init	18
2. hw_timer_arm	18
3. hw_timer_set_func.....	18
4. hardware timer example	19
3.3. System APIs	20
1. system_get_sdk_version.....	20
2. system_restore	20
3. system_restart	20
4. system_init_done_cb	21
5. system_get_chip_id	21
6. system_get_vdd33	21
7. system_adc_read	22
8. system_deep_sleep	22
9. system_deep_sleep_set_option.....	23
10. system_phy_set_rfoption	23
11. system_phy_set_max_tpw	24
12. system_phy_set_tpw_via_vdd33.....	25
13. system_set_os_print	25
14. system_print_meminfo.....	25
15. system_get_free_heap_size	26



16.	system_os_task.....	26
17.	system_os_post	27
18.	system_get_time.....	28
19.	system_get_rtc_time.....	28
20.	system_rtc_clock_cali_proc	28
21.	system_rtc_mem_write	29
22.	system_rtc_mem_read	30
23.	system_uart_swap.....	30
24.	system_uart_de_swap	31
25.	system_get_boot_version	31
26.	system_get_userbin_addr	31
27.	system_get_boot_mode	32
28.	system_restart_enhance	32
29.	system_update_cpu_freq.....	33
30.	system_get_cpu_freq.....	33
31.	system_get_flash_size_map.....	33
32.	system_get_RST_info	34
33.	system_soft_wdt_stop.....	35
34.	system_soft_wdt_restart	35
35.	os_memset.....	36
36.	os_memcpy.....	36
37.	os_strlen.....	36
38.	os_printf	37
39.	os_bzero.....	37
40.	os_delay_us.....	38
41.	os_install_putc1	38
3.4.	SPI Flash Related APIs.....	38
1.	spi_flash_get_id	38
2.	spi_flash_erase_sector.....	39
3.	spi_flash_write	39
4.	spi_flash_read.....	40
5.	system_param_save_with_protect	40
6.	system_param_load	41



7. spi_flash_set_read_func.....	42
3.5. Wi-Fi Related APIs.....	44
1. wifi_get_opmode	44
2. wifi_get_opmode_default	44
3. wifi_set_opmode.....	45
4. wifi_set_opmode_current	45
5. wifi_station_get_config.....	45
6. wifi_station_get_config_default.....	46
7. wifi_station_set_config	46
8. wifi_station_set_config_current	47
9. wifi_station_connect	48
10. wifi_station_disconnect	48
11. wifi_station_get_connect_status	49
12. wifi_station_scan	49
13. scan_done_cb_t	50
14. wifi_station_ap_number_set.....	50
15. wifi_station_get_ap_info.....	51
16. wifi_station_ap_change.....	51
17. wifi_station_get_current_ap_id	51
18. wifi_station_get_auto_connect	52
19. wifi_station_set_auto_connect	52
20. wifi_station_dhcpc_start	52
21. wifi_station_dhcpc_stop	53
22. wifi_station_dhcpc_status	53
23. wifi_station_set_reconnect_policy	54
24. wifi_station_get_rssi	54
25. wifi_station_set_hostname	54
26. wifi_station_get_hostname	55
27. wifi_softap_get_config	55
28. wifi_softap_get_config_default	55
29. wifi_softap_set_config	56
30. wifi_softap_set_config_current	56
31. wifi_softap_get_station_num	57



32. wifi_softap_get_station_info	57
33. wifi_softap_free_station_info	57
34. wifi_softap_dhcps_start	58
35. wifi_softap_dhcps_stop	59
36. wifi_softap_set_dhcps_lease.....	59
37. wifi_softap_dhcps_status.....	60
38. wifi_softap_set_dhcps_offer_option	61
39. wifi_set_phy_mode	62
40. wifi_get_phy_mode.....	62
41. wifi_get_ip_info	62
42. wifi_set_ip_info	63
43. wifi_set_macaddr.....	64
44. wifi_get_macaddr	65
45. wifi_set_sleep_type.....	65
46. wifi_get_sleep_type.....	65
47. wifi_status_led_install.....	66
48. wifi_status_led_uninstall	66
49. wifi_set_broadcast_if.....	67
50. wifi_get_broadcast_if	67
51. wifi_set_event_handler_cb	67
52. wifi_get_channel	69
53. wifi_set_channel	69
54. wifi_wps_enable	70
55. wifi_wps_disable	70
56. wifi_wps_start	71
57. wifi_set_wps_cb	71
3.6. ESP-NOW APIs.....	73
1. esp_now_init.....	73
2. esp_now_deinit.....	73
3. esp_now_register_recv_cb	73
4. esp_now_unregister_recv_cb.....	74
5. esp_now_send	74
6. esp_now_add_peer	75



7.	esp_now_del_peer.....	75
8.	esp_now_set_self_role.....	76
9.	esp_now_get_self_role.....	76
10.	esp_now_set_peer_role	77
11.	esp_now_get_peer_role.....	77
12.	esp_now_set_peer_key	78
13.	esp_now_get_peer_key	78
14.	esp_now_set_peer_channel.....	78
15.	esp_now_get_peer_channel	79
16.	esp_now_is_peer_exist	79
17.	esp_now_fetch_peer	80
18.	esp_now_get_cnt_info	80
3.7.	Upgrade (FOTA) APIs.....	81
1.	system_upgrade_userbin_check.....	81
2.	system_upgrade_flag_set	81
3.	system_upgrade_flag_check.....	81
4.	system_upgrade_start	82
5.	system_upgrade_reboot	82
3.8.	Sniffer Related APIs.....	83
1.	wifi_promiscuous_enable	83
2.	wifi_promiscuous_set_mac	83
3.	wifi_set_promiscuous_rx_cb	84
3.9.	smart config APIs	85
1.	smartconfig_start	85
2.	smartconfig_stop	87
3.10.	SNTP APIs	88
1.	sntp_setserver	88
2.	sntp_getserver.....	88
3.	sntp_setservername	88
4.	sntp_getservername	89
5.	sntp_init.....	89
6.	sntp_stop	89
7.	sntp_get_current_timestamp	89



8.	sntp_get_real_time.....	90
9.	SNTP Example	91
4.	TCP/UDP APIs.....	92
4.1.	Generic TCP/UDP APIs	92
1.	espconn_delete	92
2.	espconn_gethostbyname	92
3.	espconn_port	93
4.	espconn_regist_sentcb.....	94
5.	espconn_regist_recvcb	94
6.	espconn_sent_callback	95
7.	espconn_recv_callback.....	95
8.	espconn_sent	95
4.2.	TCP APIs	96
1.	espconn_accept	96
2.	espconn_secure_accept.....	97
3.	espconn_regist_time.....	97
4.	espconn_get_connection_info	98
5.	espconn_connect	98
6.	espconn_connect_callback.....	99
7.	espconn_regist_connectcb	99
8.	espconn_set_opt	100
9.	espconn_clear_opt	101
10.	espconn_set_keepalive.....	101
11.	espconn_get_keepalive	103
12.	espconn_reconnect_callback.....	103
13.	espconn_regist_reconcb.....	104
14.	espconn_disconnect.....	105
15.	espconn_regist_disconcb	105
16.	espconn_regist_write_finish	105
17.	espconn_secure_set_size	106
18.	espconn_secure_get_size.....	107
19.	espconn_secure_connect	107
20.	espconn_secure_sent	108



21. espconn_secure_disconnect	108
22. espconn_secure_ca_disable.....	109
23. espconn_secure_ca_enable.....	109
24. espconn_tcp_get_max_con.....	110
25. espconn_tcp_set_max_con	110
26. espconn_tcp_get_max_con_allow	110
27. espconn_tcp_set_max_con_allow	111
28. espconn_recv_hold.....	111
29. espconn_recv_unhold.....	112
4.3. UDP APIs	112
1. espconn_create	112
2. espconn_igmp_join.....	113
3. espconn_igmp_leave	113
4. espconn_dns_setserver	113
4.4. mDNS APIs.....	114
1. espconn_mdns_init	114
2. espconn_mdns_close	115
3. espconn_mdns_server_register	115
4. espconn_mdns_server_unregister.....	115
5. espconn_mdns_getservername	116
6. espconn_mdns_setservername	116
7. espconn_mdns_set_hostname	116
8. espconn_mdns_get_hostname	117
9. espconn_mdns_disable	117
10. espconn_mdns_enable.....	117
5. Application Related	118
5.1. AT APIs	118
1. at_response_ok	118
2. at_response_error.....	118
3. at_cmd_array_regist	118
4. at_get_next_int_dec.....	119
5. at_data_str_copy	119
6. at_init.....	120



7. at_port_print	120
8. at_set_custom_info.....	120
9. at_enter_special_state	121
10. at_leave_special_state	121
11. at_get_version	121
12. at_register_uart_rx_intr.....	122
13. at_response.....	122
14. at_register_response_func	123
5.2. Related JSON APIs.....	124
1. jsonparse_setup	124
2. jsonparse_next	124
3. jsonparse_copy_value.....	124
4. jsonparse_get_value_as_int	125
5. jsonparse_get_value_as_long	125
6. jsonparse_get_len.....	125
7. jsonparse_get_value_as_type	126
8. jsonparse_strcmp_value	126
9. jsontree_set_up	126
10. jsontree_reset	127
11. jsontree_path_name	127
12. jsontree_write_int	128
13. jsontree_write_int_array	128
14. jsontree_write_string	128
15. jsontree_print_next	129
16. jsontree_find_next.....	129
6. Definitions & Structures.....	130
6.1. Timer.....	130
6.2. WiFi Related Structures	130
1. Station Related	130
2. soft-AP related.....	130
3. scan related.....	131
4. WiFi event related structure.....	131
5. smart config structure	134



6.3.	JSON Related Structure	134
1.	json structure.....	134
2.	json macro definition.....	135
6.4.	espconn parameters.....	136
1.	callback function.....	136
2.	espconn	136
6.5.	interrupt related definition.....	138
7.	Peripheral Related Drivers.....	140
7.1.	GPIO Related APIs	140
1.	PIN Related Macros	140
2.	gpio_output_set.....	140
3.	GPIO input and output macro	141
4.	GPIO interrupt	141
5.	gpio_pin_intr_state_set	141
6.	GPIO Interrupt Handler	142
7.2.	UART Related APIs.....	142
1.	uart_init.....	142
2.	uart0_tx_buffer.....	143
3.	uart0_rx_intr_handler	143
7.3.	I2C Master Related APIs	144
1.	i2c_master_gpio_init	144
2.	i2c_master_init.....	144
3.	i2c_master_start	144
4.	i2c_master_stop	145
5.	i2c_master_send_ack	145
6.	i2c_master_send_nack	145
7.	i2c_master_checkAck	145
8.	i2c_master_readByte	146
9.	i2c_master_writeByte.....	146
7.4.	PWM Related.....	147
1.	pwm_init	147
2.	pwm_start	148
3.	pwm_set_duty	148



4. pwm_get_duty.....	148
5. pwm_set_period	149
6. pwm_get_period	149
7. get_pwm_version	149
8. Appendix.....	150
8.1. ESPCONN Programming.....	150
1. TCP Client Mode	150
2. TCP Server Mode	150
3. espconn callback	151
8.2. RTC APIs Example	151
8.3. Sniffer Structure Introduction	153
8.4. ESP8266 soft-AP and station channel configuration	157



1. Preambles

ESP8266 WiFi SoC offers a complete and self-contained Wi-Fi networking solution; it can be used to host the application or to offload Wi-Fi networking functions from another application processor. When ESP8266 hosts the application, it boots up directly from an external flash. It has integrated cache to improve the performance of the system in such applications. Alternately, serving as a Wi-Fi adapter, wireless internet access can be added to any microcontroller-based design with simple connectivity through UART interface or the CPU AHB bridge interface.

ESP8266EX is amongst the most integrated WiFi chip in the industry; it integrates the antenna switches, RF balun, power amplifier, low noise receive amplifier, filters, power management modules, it requires minimal external circuitry, and the entire solution, including front-end module, is designed to occupy minimal PCB area.

ESP8266EX also integrates an enhanced version of Tensilica's L106 Diamond series 32-bit processor, with on-chip SRAM, besides the Wi-Fi functionalities. ESP8266EX is often integrated with external sensors and other application specific devices through its GPIOs; codes for such applications are provided in examples in the SDK.

Sophisticated system-level features include fast sleep/wake context switching for energy-efficient VoIP, adaptive radio biasing for low-power operation, advance signal processing, and spur cancellation and radio co-existence features for common cellular, Bluetooth, DDR, LVDS, LCD interference mitigation.

The SDK based on ESP8266 IoT platform offers users an easy, fast and efficient way to develop IoT devices. This programming guide provides overview of the SDK as well as details on the API. It is written for embedded software developers to help them program on ESP8266 IoT platform.



2. Overview

The SDK provides a set of interfaces for data receive and transmit functions over the Wi-Fi and TCP/IP layer so programmers can focus on application development on the high level. Users can easily make use of the corresponding interfaces to realize data receive and transmit.

All networking functions on the ESP8266 IoT platform are realized in the library, and are not transparent to users. Instead, users can initialize the interface in [user_main.c](#).

`void user_init(void)` is the default method provided. Users can add functions like firmware initialization, network parameters setting, and timer initialization in the interface.

`void user_rf_pre_init(void)` need to be added in [user_main.c](#) since SDK_v1.1.0, refer to IOT_Demo. It is provided for RF initialization. User can call `system_phy_set_rfoption` to set RF option in [user_rf_pre_init](#), or call `system_deep_sleep_set_option` before deep-sleep. If RF is disable, ESP8266 station and soft-AP are both disabled, please don't call related APIs.

The SDK provides APIs to handle JSON, and users can also use self-defined data types to handle them.

Notice:

- Using non-OS SDK which is single-threaded, any task should not occupy CPU too long;
 - ▶ If a task occupied CPU for a long time, ESP8266 can't feed the dog, will cause a watchdog reset;
 - ▶ Task should not occupy CPU more than 10 ms, otherwise may cause Wi-Fi connection break.
- We suggest to use a timer to check periodically.
- Using non-OS SDK, please don't call any function defined with `ICACHE_FLASH_ATTR` in interrupt handler.
- We suggest to use RTOS SDK, RTOS can schedule different tasks.



3. Application Programming Interface (APIs)

3.1. Software Timer

Timer APIs can be found: [/esp_iot_sdk/include/osapi.h](#). Please be noted that `os_timer` APIs listed below are software timer, they are executed in task, so timer callback may not be precisely executed at the right time, it depends on priority. If you need a precise timer, please use hardware timer which will be executed in hardware interrupt, refer to [hw_timer.c](#).

- For the same timer, `os_timer_arm` (or `os_timer_arm_us`) cannot be invoked repeatedly. `os_timer_disarm` should be invoked first.
- `os_timer_setfn` can only be invoked when the timer is not enabled, i.e., after `os_timer_disarm` or before `os_timer_arm` (or `os_timer_arm_us`).

1. `os_timer_arm`

Function:

Enable a millisecond timer.

Prototype:

```
void os_timer_arm (
    ETSTimer *ptimer,
    uint32_t milliseconds,
    bool repeat_flag
)
```

Parameters:

```
ETSTimer *ptimer : Timer structure
uint32_t milliseconds : Timing, Unit: millisecond
    ▶ if called system_timer_reinit, the maximum value allowed to input is
        0x41893
    ▶ if didn't call system_timer_reinit, the maximum value allowed to input
        is 0xFFFFFFF
bool repeat_flag : Whether the timer will be invoked repeatedly or not
```

Return:

null



2. os_timer_disarm

Function:

Disarm timer

Prototype:

```
void os_timer_disarm (ETSTimer *ptimer)
```

Parameters:

`ETSTimer *ptimer` : Timer structure

Return:

null

3. os_timer_setfn

Function:

Set timer callback function.

For enabled timer, timer callback has to be set.

Prototype:

```
void os_timer_setfn(  
    ETSTimer *ptimer,  
    ETSTimerFunc *pfunction,  
    void *parg  
)
```

Parameters:

`ETSTimer *ptimer` : Timer structure
`TESTimerFunc *pfunction` : timer callback function
`void *parg` : callback function parameter

Return:

null

4. system_timer_reinit

Function:

Reinitiate the timer when you need to use microsecond timer

Notes:

1. Define `USE_US_TIMER`;
2. Put `system_timer_reinit` at the beginning of `user_init` , in the first sentence.

Prototype:

```
void system_timer_reinit (void)
```

**Parameters:**

null

Return:

null

5. os_timer_arm_us

Function:

Enable a microsecond timer.

Notes:

1. Define `USE_US_TIMER`;
2. Put `system_timer_reinit` at the beginning of `user_init` , in the first sentence.

Prototype:

```
void os_timer_arm_us (
    ETSTimer *ptimer,
    uint32_t microseconds,
    bool repeat_flag
)
```

Parameters:

`ETSTimer *ptimer` : Timer structure
`uint32_t microseconds` : Timing, Unit: microsecond, the minimum value is `0x64`, the maximum value allowed to input is `0xFFFFFFFF`
`bool repeat_flag` : Whether the timer will be invoked repeatedly or not

Return:

null

3.2. Hardware Timer

Hardware timer APIs can be found in `/esp_iot_sdk/examples/driver_lib/hw_timer.c`. User can use it according to "`readme.txt`" which in folder `driver_lib`.

NOTE:

- if use NMI source, for autoload timer , parameter `val` of `hw_timer_arm` can't be less than 100.
- if use NMI source, this timer has highest priority, can interrupt other ISR.
- if use FRC1 source, this timer can't interrupt other ISR.
- APIs in `hw_timer.c` can not be called when PWM APIs are using, because they are using the same hardware timer.



1. hw_timer_init

Function:

Initialize the hardware ISR timer

Prototype:

```
void hw_timer_init (
    FRC1_TIMER_SOURCE_TYPE source_type,
    u8 req
)
```

Parameters:

FRC1_TIMER_SOURCE_TYPE source_type : ISR source of timer
FRC1_SOURCE, timer use FRC1 ISR as ISR source.
NMI_SOURCE, timer use NMI ISR as ISR source.
u8 req : 0, not autoload
1, autoload mode

Return:

none

2. hw_timer_arm

Function:

Set a trigger timer delay to enable this timer.

Prototype:

```
void hw_timer_arm (uint32 val)
```

Parameters:

uint32 val : Timing
• in autoload mode :
 ▶ For FRC1_SOURCE, range : 50 ~ 0xfffff;
 ▶ For NMI_SOURCE, range : 100 ~ 0xfffff;
• in non autoload mode, range : 10 ~ 0xfffff;

Return:

none

3. hw_timer_set_func

Function:

Set timer callback function.



For enabled timer, timer callback has to be set.

Prototype:

```
void hw_timer_set_func (void (* user_hw_timer_cb_set)(void) )
```

Parameters:

```
void (* user_hw_timer_cb_set)(void) : Timer callback function
```

Return:

```
none
```

4. hardware timer example

```
#define REG_READ(_r)      (*(volatile uint32 *)(_r))
#define WDEV_NOW()        REG_READ(0x3ff20c00)

uint32 tick_now2 = 0;
void hw_test_timer_cb(void)
{
    static uint16 j = 0;
    j++;

    if( (WDEV_NOW() - tick_now2) >= 1000000 )
    {
        static u32 idx = 1;
        tick_now2 = WDEV_NOW();
        os_printf("b%u:%d\n",idx++,j);
        j = 0;
    }
}

void ICACHE_FLASH_ATTR user_init(void)
{
    hw_timer_init(FRC1_SOURCE,1);
    hw_timer_set_func(hw_test_timer_cb);
    hw_timer_arm(100);
}
```



3.3. System APIs

1. system_get_sdk_version

Function:

Get SDK version

Prototype:

```
const char* system_get_sdk_version(void)
```

Parameter:

none

Return:

SDK version

Example:

```
os_printf("SDK version: %s \n", system_get_sdk_version());
```

2. system_restore

Function:

Reset to default settings of following APIs : `wifi_station_set_auto_connect`, `wifi_set_phy_mode`, `wifi_softap_set_config` related, `wifi_station_set_config` related, `wifi_set_opmode`, and APs information recorded by `#define AP_CACHE`

Prototype:

```
void system_restore(void)
```

Parameters:

null

Return:

null

3. system_restart

Function:

Restart

Prototype:

```
void system_restart(void)
```

Parameters:

null



Return:
null

4. system_init_done_cb

Function:

Call this API in `user_init` to register a system-init-done callback.

Note:

`wifi_station_scan` has to be called after system init done and station enable.

Prototype:

```
void system_init_done_cb(init_done_cb_t cb)
```

Parameter:

```
init_done_cb_t cb : system-init-done callback
```

Return:

null

Example:

```
void to_scan(void) { wifi_station_scan(null,scan_done); }
void user_init(void) {
    wifi_set_opmode(STATION_MODE);
    system_init_done_cb(to_scan);
}
```

5. system_get_chip_id

Function:

Get chip ID

Prototype:

```
uint32 system_get_chip_id (void)
```

Parameters:

null

Return:

Chip ID

6. system_get_vdd33

Function:

Measure the power voltage of VDD3P3 pin 3 and 4, unit: 1/1024 V

Note:



- `system_get_vdd33` can only be called when TOUT pin is suspended
- The 107th byte in `esp_init_data_default.bin` (0~127byte) is named as "vdd33_const", when TOUT pin is suspended vdd33_const must be set as 0xFF, that is 255

Prototype:

```
uint16 system_get_vdd33(void)
```

Parameter:

none

Return:

power voltage of VDD33, unit: 1/1024 V

7. `system_adc_read`

Function:

Measure the input voltage of TOUT pin 6, unit: 1/1024 V

Note:

- `system_adc_read` is only available when wire TOUT pin to external circuitry, Input Voltage Range restricted to 0 ~ 1.0V.
- The 107th byte in `esp_init_data_default.bin`(0~127byte) is named as "vdd33_const", and when wire TOUT pin to external circuitry, the vdd33_const must be set as real power voltage of VDD3P3 pin 3 and 4.
- The range of operating voltage of ESP8266 is 1.8V~3.6V, the unit of vdd33_const is 0.1V, so effective value range of vdd33_const is [18, 36].

Prototype:

```
uint16 system_adc_read(void)
```

Parameter:

none

Return:

input voltage of TOUT pin 6, unit: 1/1024 V

8. `system_deep_sleep`

Function:

Configures chip for deep-sleep mode. When the device is in deep-sleep, it automatically wakes up periodically; the period is configurable. Upon waking up, the device boots up from `user_init`.

**Note:**

- Hardware has to support deep-sleep wake up (`XPD_DCDC` connects to `EXT_RSTB` with 0R).
- `system_deep_sleep(0)`: there is no wake up timer; in order to wakeup, connect a GPIO to pin `RST`, the chip will wake up by a falling-edge on pin `RST`

Prototype:

```
void system_deep_sleep(uint32 time_in_us)
```

Parameters:

`uint32 time_in_us` : during the time (us) device is in deep-sleep

Return:

`null`

9. `system_deep_sleep_set_option`

Function:

Call this API before `system_deep_sleep` to set what the chip will do when next deep-sleep wake up.

Prototype:

```
bool system_deep_sleep_set_option(uint8 option)
```

Parameter:

`uint8 option` :

- `deep_sleep_set_option(0)`: Radio calibration after deep-sleep wake up depends on `esp_init_data_default.bin` (0~127byte) byte 108.
- `deep_sleep_set_option(1)`: Radio calibration is done after deep-sleep wake up; this increases the current consumption.
- `deep_sleep_set_option(2)`: No radio calibration after deep-sleep wake up; this reduces the current consumption.
- `deep_sleep_set_option(4)`: Disable RF after deep-sleep wake up, just like modem sleep; this has the least current consumption; the device is not able to transmit or receive data after wake up.

Return:

`true` : succeed
`false` : fail

10. `system_phy_set_rfoption`

Function:

Enable RF or not when wakeup from deep-sleep.

**Note:**

- This API can only be called in `user_rf_pre_init`.
- Function of this API is similar to `system_deep_sleep_set_option`, if they are both called, it will disregard `system_deep_sleep_set_option` which is called before deep-sleep, and refer to `system_phy_set_rfoption` which is called when deep-sleep wake up.
- Before calling this API, `system_deep_sleep_set_option` should be called once at least.

Prototype:

```
void system_phy_set_rfoption(uint8 option)
```

Parameter:

`uint8 option :`

`system_phy_set_rfoption(0)` : Radio calibration after deep-sleep wake up depends on `esp_init_data_default.bin` (0~127byte) byte 108.

`system_phy_set_rfoption(1)` : Radio calibration is done after deep-sleep wake up; this increases the current consumption.

`system_phy_set_rfoption(2)` : No radio calibration after deep-sleep wake up; this reduces the current consumption.

`system_phy_set_rfoption(4)` : Disable RF after deep-sleep wake up, just like modem sleep; this has the least current consumption; the device is not able to transmit or receive data after wake up.

Return:

none

11. `system_phy_set_max_tpw`

Function:

Set maximum value of RF TX Power, unit : 0.25dBm

Prototype:

```
void system_phy_set_max_tpw(uint8 max_tpw)
```

Parameter:

`uint8 max_tpw` : maximum value of RF Tx Power, unit : 0.25dBm, range [0, 82]
it can be set refer to the 34th byte (`target_power_qdb_0`) of
`esp_init_data_default.bin`(0~127byte)

Return:

none



12. system_phy_set_tpw_via_vdd33

Function:

Adjust RF TX Power according to VDD33, unit : 1/1024 V

Note:

When TOUT pin is suspended, VDD33 can be got by `system_get_vdd33`;

When wire TOUT pin to external circuitry, `system_get_vdd33` can not be used.

Prototype:

```
void system_phy_set_tpw_via_vdd33(uint16 vdd33)
```

Parameter:

`uint16 vdd33` : VDD33, unit : 1/1024V, range [1900, 3300]

Return:

none

13. system_set_os_print

Function:

Turn on/off print logFunction

Prototype:

```
void system_set_os_print (uint8 onoff)
```

Parameters:

`uint8 onoff`

Note:

`onoff==0`: print function off

`onoff==1`: print function on

Default:

print function on

Return:

null

14. system_print_meminfo

Function:

Print memory information, including data/rodata/bss/heap

Prototype:

```
void system_print_meminfo (void)
```

**Parameters:**

null

Return:

null

15. system_get_free_heap_size

Function:

Get free heap size

Prototype:

```
uint32 system_get_free_heap_size(void)
```

Parameters:

null

Return:

uint32 : available heap size

16. system_os_task

Function:

Set up tasks

Prototype:

```
bool system_os_task(
    os_task_t    task,
    uint8        prio,
    os_event_t   *queue,
    uint8        qlen
)
```

Parameters:

`os_task_t task` : task function
`uint8 prio` : task priority. 3 priorities are supported: 0/1/2; 0 is the lowest priority. This means only 3 tasks is allowed to set up.
`os_event_t *queue` : message queue pointer
`uint8 qlen` : message queue depth

Return:

true: succeed
false: fail

**Example:**

```
#define SIG_RX      0
#define TEST_QUEUE_LEN  4
os_event_t *testQueue;
void test_task (os_event_t *e) {
    switch (e->sig) {
        case SIG_RX:
            os_printf(sig_rx %c/n, (char)e->par);
            break;
        default:
            break;
    }
}
void task_init(void) {
    testQueue=(os_event_t *)os_malloc(sizeof(os_event_t)*TEST_QUEUE_LEN);
    system_os_task(test_task,USER_TASK_PRIO_0,testQueue,TEST_QUEUE_LEN);
}
```

17. system_os_post

Function: send message to task

Prototype:

```
bool system_os_post (
    uint8 prio,
    os_signal_t sig,
    os_param_t par
)
```

Parameters:

```
uint8 prio      : task priority, corresponding to that you set up
os_signal_t sig : message type
os_param_t par  : message parameters
```

Return:

```
true: succeed
false: fail
```

Referring to the above example:

```
void task_post(void) {
    system_os_post(USER_TASK_PRIO_0, SIG_RX, 'a');
}
```

Printout:

```
sig_rx a
```



18. system_get_time

Function:

Get system time (us).

Prototype:

```
uint32 system_get_time(void)
```

Parameter:

null

Return:

System time in microsecond.

19. system_get_rtc_time

Function: Get RTC time, as denoted by the number of RTC clock periods.

Example:

If `system_get_rtc_time` returns 10 (it means 10 RTC cycles), and `system_rtc_clock_cali_proc` returns 5.75 (means 5.75us per RTC cycle), then the real time is $10 \times 5.75 = 57.5$ us.

Note:

System time will return to zero because of `system_restart`, but RTC still goes on.

- reset by pin `EXT_RST` : RTC memory won't change, RTC timer returns to zero
- watchdog reset : RTC memory won't change, RTC timer won't change
- `system_restart` : RTC memory won't change, RTC timer won't change
- power on : RTC memory is random value, RTC timer starts from zero
- reset by pin `CHIP_EN` : RTC memory is random value, RTC timer starts from zero

Prototype:

```
uint32 system_get_rtc_time(void)
```

Parameter:

null

Return:

RTC time

20. system_rtc_clock_cali_proc

Function:

Get RTC clock period.

**Note:**

RTC clock period has decimal part.

RTC clock period will change according to temperature, so RTC timer is not very precise.

Prototype:

```
uint32 system_rtc_clock_cali_proc(void)
```

Parameter:

null

Return:

RTC clock period (in us), bit11~ bit0 are decimal. ((RTC_CAL * 100)>> 12)


Note:

see RTC demo in Appendix.

21. system_rtc_mem_write

Function:

During deep sleep, only RTC still working, so maybe we need to save some user data in RTC memory. Only user data area can be used by user.

**Note:**

RTC memory is 4 bytes aligned for read and write operations. Parameter `des_addr` means block number(4 bytes per block). So, if we want to save some data at the beginning of user data area, `des_addr` will be $256/4 = 64$, `save_size` will be data length.

Prototype:

```
bool system_rtc_mem_write (
    uint32 des_addr,
    void * src_addr,
    uint32 save_size
)
```

Parameter:

```
uint32 des_addr : destination address (block number) in RTC memory,  
des_addr >=64  
void * src_addr : data pointer.  
uint32 save_size : data length ( byte)
```

**Return:**

true: succeed
false: fail

22. system_rtc_mem_read

Function:

Read user data from RTC memory. Only user data area should be accessed by the user.

**Note:**

RTC memory is 4 bytes aligned for read and write operations. Parameter `src_addr` means block number(4 bytes per block). So, to read data from the beginning of user data area, `src_addr` will be $256/4=64$, `save_size` will be data length.

Prototype:

```
bool system_rtc_mem_read (
    uint32 src_addr,
    void * des_addr,
    uint32 save_size
)
```

Parameter:

```
uint32 src_addr : source address (block number) in rtc memory, src_addr >=
64
void * des_addr : data pointer
uint32 save_size : data length, byte
```

Return:

true: succeed
false: fail

23. system_uart_swap

Function:

UART0 swap. Use MTCK as UART0 RX, MTD0 as UART0 TX, so ROM log will not output from this new UART0. We also need to use MTD0 (U0CTS) and MTCK (U0RTS) as UART0 in hardware.

Prototype:

```
void system_uart_swap (void)
```

**Parameter:**

null

Return:

null

24. system_uart_de_swap

Function:

Disable UART0 swap. Use original UART0, not MTCK and MTD0.

Prototype:

```
void system_uart_de_swap (void)
```

Parameter:

null

Return:

null

25. system_get_boot_version

Function:

Get version info of boot

Prototype:

```
uint8 system_get_boot_version (void)
```

Parameter:

null

Return:

Version info of boot.

Note:

If boot version ≥ 3 , you could enable boot enhance mode (refer to [system_restart_enhance](#))

26. system_get_userbin_addr

Function: Get address of the current running user bin (user1.bin or user2.bin).

Prototype:

```
uint32 system_get_userbin_addr (void)
```

Parameter:

null

**Return:**

Start address info of the current running user bin.

27. system_get_boot_mode

Function: Get boot mode.

Prototype:

```
uint8 system_get_boot_mode (void)
```

Parameter:

null

Return:

```
#define SYS_BOOT_ENHANCE_MODE 0  
#define SYS_BOOT_NORMAL_MODE 1
```

Note:

Enhance boot mode: can load and run FW at any address;

Normal boot mode: can only load and run normal user1.bin (or user2.bin).

28. system_restart_enhance

Function:

Restarts system, and enters enhance boot mode.

Prototype:

```
bool system_restart_enhance(  
    uint8 bin_type,  
    uint32 bin_addr  
)
```

Parameter:

```
uint8 bin_type : type of bin  
#define SYS_BOOT_NORMAL_BIN 0 // user1.bin or user2.bin  
#define SYS_BOOT_TEST_BIN 1 // can only be Espressif test bin  
uint32 bin_addr : start address of bin file
```

Return:

true: succeed

false: Fail

Note:

SYS_BOOT_TEST_BIN is for factory test during production; you can apply for the test bin from Espressif Systems.



29. system_update_cpu_freq

Function:

Set CPU frequency. Default is 80MHz.

Prototype:

```
bool system_update_cpu_freq(uint8 freq)
```

Parameter:

```
uint8 freq : CPU frequency  
#define SYS_CPU_80MHz 80  
#define SYS_CPU_160MHz 160
```

Return:

true: succeed
false: fail

30. system_get_cpu_freq

Function:

Get CPU frequency.

Prototype:

```
uint8 system_get_cpu_freq(void)
```

Parameter:

null

Return:

CPU frequency, unit : MHz.

31. system_get_flash_size_map

Function:

Get current flash size and flash map.

Flash map depends on the selection when compiling, more details in document
“2A-ESP8266__IOT_SDK_User_Manual”

Structure:

```
enum flash_size_map {  
    FLASH_SIZE_4M_MAP_256_256 = 0,  
    FLASH_SIZE_2M,  
    FLASH_SIZE_8M_MAP_512_512,  
    FLASH_SIZE_16M_MAP_512_512,  
    FLASH_SIZE_32M_MAP_512_512,
```



```
    FLASH_SIZE_16M_MAP_1024_1024,  
    FLASH_SIZE_32M_MAP_1024_1024  
};  
Prototype:  
enum flash_size_map system_get_flash_size_map(void)  
Parameter:  
none  
Return:  
flash map
```

32. system_get_rst_info

Function:

Get information about current startup.

Structure:

```
enum rst_reason {  
    REASON_DEFAULT_RST      = 0,    // normal startup by power on  
    REASON_WDT_RST          = 1,    // hardware watch dog reset  
    // exception reset, GPIO status won't change  
    REASON_EXCEPTION_RST    = 2,  
    // software watch dog reset, GPIO status won't change  
    REASON_SOFT_WDT_RST     = 3,  
    // software restart ,system_restart , GPIO status won't change  
    REASON_SOFT_RESTART     = 4,  
    REASON_DEEP_SLEEP_AWAKE = 5,    // wake up from deep-sleep  
};  
  
struct rst_info {  
    uint32 reason;    // enum rst_reason  
    uint32 exccause;  
    uint32 epc1;  
    uint32 epc2;  
    uint32 epc3;  
    uint32 excvaddr;  
    uint32 depc;  
};
```

**Prototype:**

```
struct rst_info* system_get_rst_info(void)
```

Parameter:

none

Return:

Information about startup.

33. system_soft_wdt_stop

Function:

Stop software watchdog

Note:

Please don't stop software watchdog too long (less than 6 seconds), otherwise it will trigger hardware watchdog reset.

Prototype:

```
void system_soft_wdt_stop(void)
```

Parameter:

none

Return:

none

34. system_soft_wdt_restart

Function:

Restart software watchdog

Note:

This API can only be called if software watchdog is stopped
([system_soft_wdt_stop](#))

Prototype:

```
void system_soft_wdt_restart(void)
```

Parameter:

none

Return:

none



35. os_memset

Function:

Set value of memory

Prototype:

```
os_memset(void *s, int ch, size_t n)
```

Parameter:

`void *s` – pointer of memory

`int ch` – set value

`size_t n` – size

Return:

none

Example:

```
uint8 buffer[32];  
os_memset(buffer, 0, sizeof(buffer));
```

36. os_memcpy

Function:

copy memory

Prototype:

```
os_memcpy(void *des, void *src, size_t n)
```

Parameter:

`void *des` – pointer of destination

`void *src` – pointer of source

`size_t n` – memory size

Return:

none

Example:

```
uint8 buffer[4] = {0};  
os_memcpy(buffer, "abcd", 4);
```

37. os_strlen

Function:

Get string length

**Prototype:**

```
os_strlen(char *s)
```

Parameter:

```
char *s - string
```

Return:

```
string length
```

Example:

```
char *ssid = "ESP8266";  
os_memcpy(softAP_config.ssid, ssid, os_strlen(ssid));
```

38. os_printf

Function:

```
print format
```

Note:

Default to be output from UART 0. `uart_init` in `IOT_Demo` can set baud rate of UART, and `os_install_putc1((void *)uart1_write_char)` in it will set `os_printf` to be output from UART 1.

Prototype:

```
os_printf(const char *s)
```

Parameter:

```
const char *s - string
```

Return:

```
none
```

Example:

```
os_printf("SDK version: %s \n", system_get_sdk_version());
```

39. os_bzero

Function:

```
Set the first n bytes of string p to be 0, include '\0'
```

Prototype:

```
void os_bzero(void *p, size_t n)
```

Parameter:

```
void *p - pointer of memory need to be set 0  
size_t n - length
```

**Return:**

none

40. os_delay_us**Function:**

Time delay, max : 65535 us

Prototype:`void os_delay_us(uint16 us)`**Parameter:**`uint16 us - time, unit: us`**Return:**

none

41. os_install_putc1**Function:**

Register print output function.

Prototype:`void os_install_putc1(void(*p)(char c))`**Parameter:**`void(*p)(char c) - pointer of print function`**Return:**

none

Example:`os_install_putc1((void *)uart1_write_char) in uart_init will set os_printf to be output from UART 1, otherwise, os_printf default output from UART 0.`

3.4. SPI Flash Related APIs

More details about flash read/write operation in documentation "99A-SDK-Espressif IOT Flash RW Operation" <http://bbs.espressif.com/viewtopic.php?f=21&t=413>

1. spi_flash_get_id**Function:**

Get ID info of spi flash

**Prototype:**

```
uint32 spi_flash_get_id (void)
```

Parameters:

```
null
```

Return:

```
SPI flash ID
```

2. spi_flash_erase_sector

Function:

```
Erase sector in flash
```

Prototype:

```
SpiFlashOpResult spi_flash_erase_sector (uint16 sec)
```

Parameters:

```
uint16 sec : Sector number, the count starts at sector 0, 4KB per sector.
```

Return:

```
typedef enum{
    SPI_FLASH_RESULT_OK,
    SPI_FLASH_RESULT_ERR,
    SPI_FLASH_RESULT_TIMEOUT
} SpiFlashOpResult;
```

3. spi_flash_write

Function:

```
Write data to flash. Flash read/write has to be 4-bytes aligned.
```

Prototype:

```
SpiFlashOpResult spi_flash_write (
    uint32 des_addr,
    uint32 *src_addr,
    uint32 size
)
```

Parameters:

```
uint32 des_addr : destination address in flash.
uint32 *src_addr : source address of the data.
uint32 size      :length of data
```

**Return:**

```
typedef enum{
    SPI_FLASH_RESULT_OK,
    SPI_FLASH_RESULT_ERR,
    SPI_FLASH_RESULT_TIMEOUT
} SpiFlashOpResult;
```

4. spi_flash_read

Function:

Read data from flash. Flash read/write has to be 4-bytes aligned.

Prototype:

```
SpiFlashOpResult spi_flash_read(
    uint32 src_addr,
    uint32 * des_addr,
    uint32 size
)
```

Parameters:

```
uint32 src_addr: source address in flash
uint32 *des_addr: destination address to keep data.
uint32 size:      length of data
```

Return:

```
typedef enum {
    SPI_FLASH_RESULT_OK,
    SPI_FLASH_RESULT_ERR,
    SPI_FLASH_RESULT_TIMEOUT
} SpiFlashOpResult;
```

Example:

```
uint32 value;
uint8 *addr = (uint8 *)&value;
spi_flash_read(0x3E * SPI_FLASH_SEC_SIZE, (uint32 *)addr, 4);
os_printf("0x3E sec:%02x%02x%02x%02x\r\n", addr[0], addr[1], addr[2],
addr[3]);
```

5. system_param_save_with_protect

Function:

Write data into flash with protection. Flash read/write has to be 4-bytes aligned.



Protection of flash read/write : use 3 sectors (4KBytes per sector) to save 4KB data with protect, sector 0 and sector 1 are data sectors, back up each other, save data alternately, sector 2 is flag sector, point out which sector is keeping the latest data, sector 0 or sector 1.

Note:

More details about protection of flash read/write in documentation “99A-SDK-Espressif IOT Flash RW Operation” <http://bbs.espressif.com/viewtopic.php?f=21&t=413>

Prototype:

```
bool system_param_save_with_protect (
    uint16 start_sec,
    void *param,
    uint16 len
)
```

Parameter:

`uint16 start_sec` : start sector (sector 0) of the 3 sectors which used for flash read/write protection.

For example, in IOT_Demo we could use the 3 sectors ($3 * 4KB$) starts from flash `0x3D000` for flash read/write protection, so the parameter `start_sec` should be `0x3D`

`void *param` : pointer of data need to save

`uint16 len` : data length, should less than a sector which is $4 * 1024$

Return:

true, succeed;

false, fail

6. system_param_load

Function:

Read data which saved into flash with protection. Flash read/write has to be 4-bytes aligned.

Protection of flash read/write : use 3 sectors (4KBytes per sector) to save 4KB data with protect, sector 0 and sector 1 are data sectors, back up each other, save data alternately, sector 2 is flag sector, point out which sector is keeping the latest data, sector 0 or sector 1.

Note:

More details about protection of flash read/write in documentation “99A-SDK-Espressif IOT Flash RW Operation” <http://bbs.espressif.com/viewtopic.php?f=21&t=413>

**Prototype:**

```
bool system_param_load (
```



```
    uint16 start_sec,
```



```
    uint16 offset,
```



```
    void *param,
```



```
    uint16 len
```


)**Parameter:**

`uint16 start_sec` : start sector (sector 0) of the 3 sectors which used for flash read/write protection. It can not sector 1 or sector 2.

For example, in IOT_Demo we could use the 3 sectors ($3 * 4KB$) starts from flash `0x3D000` for flash read/write protection, so the parameter `start_sec` is `0x3D`, can not be `0x3E` or `0x3F`.

`uint16 offset` : offset of data saved in sector
`void *param` : data pointer
`uint16 len` : data length, `offset + len ≤ 4 * 1024`

Return:

true, succeed;
false, fail

7. spi_flash_set_read_func

Function:

Register user-define SPI flash read API.

Note:

This API can be only used in SPI overlap mode, please refer to esp_iot_sdk \examples\driver_lib\driver\spi_overlap.c

Prototype:

```
void spi_flash_set_read_func (user_spi_flash_read read)
```

Parameter:

`user_spi_flash_read read` : user-define SPI flash read API

Parameter Definition:

```
typedef SpiFlashOpResult (*user_spi_flash_read)()
```



```
    SpiFlashChip *spi,  
    uint32 src_addr,  
    uint32 * des_addr,  
    uint32 size  
)
```

Return:

none



3.5. Wi-Fi Related APIs

`wifi_station` APIs and other APIs which set/get configuration of ESP8266 station can only be called if ESP8266 station is enabled.

`wifi_softap` APIs and other APIs which set/get configuration of ESP8266 soft-AP can only be called if ESP8266 soft-AP is enabled.

Flash system parameter area is the last 16KB of flash.

1. `wifi_get_opmode`

Function:

get WiFi current operating mode

Prototype:

```
uint8 wifi_get_opmode (void)
```

Parameters:

null

Return:

WiFi working modes:

0x01: station mode

0x02: soft-AP mode

0x03: station+soft-AP

2. `wifi_get_opmode_default`

Function:

get WiFi operating mode that saved in flash

Prototype:

```
uint8 wifi_get_opmode_default (void)
```

Parameters:

null

Return:

WiFi working modes:

0x01: station mode

0x02: soft-AP mode

0x03: station+soft-AP



3. wifi_set_opmode

Function:

Sets WiFi working mode as station, soft-AP or station+soft-AP, and save it to flash. Default is soft-AP mode.

Note:

Versions before esp_iot_sdk_v0.9.2, need to call `system_restart()` after this api; after esp_iot_sdk_v0.9.2, need not to restart.

This configuration will be saved in flash system parameter area if changed.

Prototype:

```
bool wifi_set_opmode (uint8 opmode)
```

Parameters:

`uint8 opmode`: WiFi operating modes:

0x01: station mode

0x02: soft-AP mode

0x03: station+soft-AP

Return:

true: succeed

false: fail

4. wifi_set_opmode_current

Function:

Sets WiFi working mode as station, soft-AP or station+soft-AP, and won't save to flash

Prototype:

```
bool wifi_set_opmode_current (uint8 opmode)
```

Parameters:

`uint8 opmode`: WiFi operating modes:

0x01: station mode

0x02: soft-AP mode

0x03: station+soft-AP

Return:

true: succeed

false: fail

5. wifi_station_get_config

Function:

Get WiFi station current configuration

**Prototype:**

```
bool wifi_station_get_config (struct station_config *config)
```

Parameters:

```
struct station_config *config : WiFi station configuration pointer
```

Return:

```
true: succeed  
false: fail
```

6. wifi_station_get_config_default

Function:

```
Get WiFi station configuration that saved in flash
```

Prototype:

```
bool wifi_station_get_config_default (struct station_config *config)
```

Parameters:

```
struct station_config *config : WiFi station configuration pointer
```

Return:

```
true: succeed  
false: fail
```

7. wifi_station_set_config

Function:

```
Set WiFi station configuration, and save it to flash
```

Note:

- This API can be called only if ESP8266 station is enabled.
- If `wifi_station_set_config` is called in `user_init`, there is no need to call `wifi_station_connect` after that, ESP8266 will connect to router automatically; otherwise, need `wifi_station_connect` to connect.
- In general, `station_config.bssid_set` need to be 0, otherwise it will check bssid which is the MAC address of AP.
- This configuration will be saved in flash system parameter area if changed.

Prototype:

```
bool wifi_station_set_config (struct station_config *config)
```

**Parameters:**

```
struct station_config *config: WiFi station configuration pointer
```

Return:

```
true: succeed  
false: fail
```

Example:

```
void ICACHE_FLASH_ATTR  
user_set_station_config(void)  
{  
    char ssid[32] = SSID;  
    char password[64] = PASSWORD;  
    struct station_config stationConf;  
  
    stationConf.bssid_set = 0; //need not check MAC address of AP  
  
    os_memcpy(&stationConf.ssid, ssid, 32);  
    os_memcpy(&stationConf.password, password, 64);  
    wifi_station_set_config(&stationConf);  
}  
void user_init(void)  
{  
    wifi_set_opmode(STATIONAP_MODE); //Set softAP + station mode  
    user_set_station_config();  
}
```

8. wifi_station_set_config_current

Function:

Set WiFi station configuration, won't save to flash

Note:

- This API can be called only if ESP8266 station is enabled.
- If `wifi_station_set_config_current` is called in `user_init`, there is no need to call `wifi_station_connect` after that, ESP8266 will connect to router automatically; otherwise, need `wifi_station_connect` to connect.
- In general, `station_config.bssid_set` need to be 0, otherwise it will check bssid which is the MAC address of AP.

Prototype:

```
bool wifi_station_set_config_current (struct station_config *config)
```

**Parameters:**

```
struct station_config *config: WiFi station configuration pointer
```

Return:

true: succeed
false: fail

9. wifi_station_connect

Function:

To connect WiFi station to AP

Note:

- If ESP8266 has already connected to a router, then we need to call `wifi_station_disconnect` first, before calling `wifi_station_connect`.
- Do not call this API in `user_init`. This API need to be called after system initialize done and ESP8266 station enable.

Prototype:

```
bool wifi_station_connect (void)
```

Parameters:

null

Return:

true: succeed
false: fail

10. wifi_station_disconnect

Function:

Disconnects WiFi station from AP

Note:

Do not call this API in `user_init`. This API need to be called after system initialize done and ESP8266 station enable.

Prototype:

```
bool wifi_station_disconnect (void)
```

Parameters:

null

Return:

true: succeed
false: fail



11. wifi_station_get_connect_status

Function:

Get connection status of WiFi station to AP

Prototype:

```
uint8 wifi_station_get_connect_status (void)
```

Parameters:

null

Return:

```
enum{  
    STATION_IDLE = 0,  
    STATION_CONNECTING,  
    STATION_WRONG_PASSWORD,  
    STATION_NO_AP_FOUND,  
    STATION_CONNECT_FAIL,  
    STATION_GOT_IP  
};
```

12. wifi_station_scan

Function:

Scan all available APs

Note:

Do not call this API in `user_init`. This API need to be called after system initialize done and ESP8266 station enable.

Prototype:

```
bool wifi_station_scan (struct scan_config *config, scan_done_cb_t cb);
```

Structure:

```
struct scan_config {  
    uint8 *ssid;        // AP's ssid  
    uint8 *bssid;       // AP's bssid  
    uint8 channel;     //scan a specific channel  
    uint8 show_hidden; //scan APs of which ssid is hidden.  
};
```

Parameters:

```
struct scan_config *config: AP config for scan  
if config==null: scan all APs  
if config.ssid==null && config.bssid==null && config.channel!=null:  
    ESP8266 will scan the specific channel.  
scan_done_cb_t cb: callback function after scan
```

**Return:**

true: succeed
false: fail

13. scan_done_cb_t

Function:

Callback function for wifi_station_scan

Prototype:

```
void scan_done_cb_t (void *arg, STATUS status)
```

Parameters:

`void *arg`: information of APs that be found, refer to struct `bss_info`
`STATUS status`: get status

Return:

null

Example:

```
wifi_station_scan(&config, scan_done);  
static void ICACHE_FLASH_ATTR scan_done(void *arg, STATUS status) {  
    if (status == OK) {  
        struct bss_info *bss_link = (struct bss_info *)arg;  
        bss_link = bss_link->next.stqe_next; //ignore first  
        ...  
    }  
}
```

14. wifi_station_ap_number_set

Function:

Sets the number of APs that will be cached for ESP8266 station mode.
Whenever ESP8266 station connects to an AP, it keeps caches a record of this AP's SSID and password. The cached ID index starts from 0.

Note:

This configuration will be saved in flash system parameter area if changed.

Prototype:

```
bool wifi_station_ap_number_set (uint8 ap_number)
```

Parameters:

`uint8 ap_number`: the number of APs can be recorded (MAX: 5)

**Return:**

true: succeed
false: fail

15. wifi_station_get_ap_info

Function:

Get information of APs recorded by ESP8266 station.

Prototype:

```
uint8 wifi_station_get_ap_info(struct station_config config[])
```

Parameters:

struct station_config config[]: information of APs, array size has to be 5.

Return:

The number of APs recorded.

Example:

```
struct station_config config[5];  
int i = wifi_station_get_ap_info(config);
```

16. wifi_station_ap_change

Function:

Switch ESP8266 station connection to AP as specified

Prototype:

```
bool wifi_station_ap_change (uint8 new_ap_id)
```

Parameters:

uint8 new_ap_id : AP's record id, start counting from 0.

Return:

true: succeed
false: fail

17. wifi_station_get_current_ap_id

Function:

Get the current record id of AP.

Prototype:

```
uint8 wifi_station_get_current_ap_id ();
```

Parameter:

null

**Return:**

The index of the AP, which ESP8266 is currently connected to, in the cached AP list.

18. wifi_station_get_auto_connect

Function:

Checks if ESP8266 station mode will connect to AP (which is cached) automatically or not when it is powered on.

Prototype:

```
uint8 wifi_station_get_auto_connect(void)
```

Parameter:

null

Return:

0: wil not connect to AP automatically;
Non-0: will connect to AP automatically.

19. wifi_station_set_auto_connect

Function:

Set whether ESP8266 station will connect to AP (which is recorded) automatically or not when power on. Default to enable auto-connect.

Note:

Call this API in `user_init`, it is effective in this current power on; call it in other place, it will be effective in next power on.

This configuration will be saved in flash system parameter area if changed.

Prototype:

```
bool wifi_station_set_auto_connect(uint8 set)
```

Parameter:

`uint8 set`: Automatically connect or not:
0: will not connect automatically
1: to connect automatically

Return:

true: succeed
false: fail

20. wifi_station_dhcpc_start

Function:

Enable ESP8266 station DHCP client.

**Note:**

DHCP default enable.

This configuration interacts with static IP API ([wifi_set_ip_info](#)):

If enable DHCP, static IP will be disabled;

If enable static IP, DHCP will be disabled;

This will depend on the last configuration.

Prototype:

```
bool wifi_station_dhcpc_start(void)
```

Parameter:

null

Return:

true: succeed

false: fail

21. [wifi_station_dhcpc_stop](#)

Function:

Disable ESP8266 station DHCP client.

Note:

DHCP default enable.

Prototype:

```
bool wifi_station_dhcpc_stop(void)
```

Parameter:

null

Return:

true: succeed

false: fail

22. [wifi_station_dhcpc_status](#)

Function: Get ESP8266 station DHCP client status.

Prototype:

```
enum dhcp_status wifi_station_dhcpc_status(void)
```

Parameter:

null

**Return:**

```
enum dhcp_status {  
    DHCP_STOPPED,  
    DHCP_STARTED  
};
```

23. wifi_station_set_reconnect_policy

Function:

Set whether reconnect or not when ESP8266 station disconnected from AP

Note:

We suggest to call this API in [user_init](#)

This API can only be called when ESP8266 station enable.

Prototype:

```
bool wifi_station_set_reconnect_policy(bool set)
```

Parameter:

`bool set` – true, enable reconnect; false, disable reconnect

Return:

true: succeed

false: fail

24. wifi_station_get_rssi

Function:

Get rssi of the AP which ESP8266 station connected to

Prototype:

```
sint8 wifi_station_get_rssi(void)
```

Parameter:

none

Return:

< 0 : succeed, return rssi

31 : fail, return error code

25. wifi_station_set_hostname

Function:



Set ESP8266 station DHCP hostname

Prototype:

```
bool wifi_station_get_hostname(char* hostname)
```

Parameter:

`char* hostname` : hostname, max length: 32

Return:

true: succeed

false: fail

26. wifi_station_get_hostname

Function:

Get ESP8266 station DHCP hostname

Prototype:

```
char* wifi_station_get_hostname(void)
```

Parameter:

none

Return:

hostname

27. wifi_softap_get_config

Function:

Get WiFi soft-AP current configuration

Prototype:

```
bool wifi_softap_get_config(struct softap_config *config)
```

Parameter:

`struct softap_config *config` : ESP8266 soft-AP config

Return:

true: succeed

false: fail

28. wifi_softap_get_config_default

Function:

Get WiFi soft-AP configuration that saved in flash

**Prototype:**

```
bool wifi_softap_get_config_default(struct softap_config *config)
```

Parameter:

```
struct softap_config *config : ESP8266 soft-AP config
```

Return:

```
true: succeed  
false: fail
```

29. wifi_softap_set_config

Function:

Set WiFi soft-AP configuration and save it to flash

Note:

- This API can be called only if ESP8266 soft-AP is enabled.
- This configuration will be saved in flash system parameter area if changed.
- In soft-AP + station mode, ESP8266 soft-AP will adjust its channel configuration to be as same as ESP8266. More details in appendix or BBS <http://bbs.espressif.com/viewtopic.php?f=10&t=324>

Prototype:

```
bool wifi_softap_set_config (struct softap_config *config)
```

Parameter:

```
struct softap_config *config : WiFi soft-AP configuration pointer
```

Return:

```
true: succeed  
false: fail
```

30. wifi_softap_set_config_current

Function:

Set WiFi soft-AP configuration, won't save it to flash

Note:

- This API can be called only if ESP8266 soft-AP is enabled.
- In soft-AP + station mode, ESP8266 soft-AP will adjust its channel configuration to be as same as ESP8266. More details in appendix or BBS <http://bbs.espressif.com/viewtopic.php?f=10&t=324>

**Prototype:**

```
bool wifi_softap_set_config_current (struct softap_config *config)
```

Parameter:

```
struct softap_config *config : WiFi soft-AP configuration pointer
```

Return:

```
true: succeed  
false: fail
```

31. [wifi_softap_get_station_num](#)

Function:

```
Number count of stations which connected to ESP8266 soft-AP
```

Prototype:

```
uint8 wifi_softap_get_station_num(void)
```

Parameter:

```
none
```

Return:

```
how many stations connected to ESP8266 soft-AP
```

32. [wifi_softap_get_station_info](#)

Function:

```
Get connected station devices under soft-AP mode, including MAC and IP
```

Note:

```
This API can not get static IP, it can only be used when DHCP enabled.
```

Prototype:

```
struct station_info * wifi_softap_get_station_info(void)
```

Input Parameters:

```
null
```

Return:

```
struct station_info* : station information structure
```

33. [wifi_softap_free_station_info](#)

Function:

```
Frees the struct station_info by calling the wifi_softap_get_station_info  
function
```

**Prototype:**

```
void wifi_softap_free_station_info(void)
```

Input Parameters:

```
null
```

Return:

```
null
```

Examples 1 (Getting MAC and IP information):

```
struct station_info * station = wifi_softap_get_station_info();
struct station_info * next_station;
while(station) {
    os_printf(bssid : MACSTR, ip : IPSTR/n,
              MAC2STR(station->bssid), IP2STR(&station->ip));
    next_station = STAILQ_NEXT(station, next);
    os_free(station); // Free it directly
    station = next_station;
}
```

Examples 2 (Getting MAC and IP information):

```
struct station_info * station = wifi_softap_get_station_info();
while(station){
    os_printf(bssid : MACSTR, ip : IPSTR/n,
              MAC2STR(station->bssid), IP2STR(&station->ip));
    station = STAILQ_NEXT(station, next);
}
wifi_softap_free_station_info(); // Free it by calling functions
```

34. wifi_softap_dhcps_start

Function: Enable ESP8266 soft-AP DHCP server.

Note:

DHCP default enable.

This configuration interacts with static IP API ([wifi_set_ip_info](#)):

If enable DHCP, static IP will be disabled;

If enable static IP, DHCP will be disabled;

This will depend on the last configuration.

Prototype:

```
bool wifi_softap_dhcps_start(void)
```

Parameter:

```
null
```

**Return:**

true: succeed
false: fail

35. wifi_softap_dhcps_stop

Function: Disable ESP8266 soft-AP DHCP server.

Note: DHCP default enable.

Prototype:

```
bool wifi_softap_dhcps_stop(void)
```

Parameter:

null

Return:

true: succeed
false: fail

36. wifi_softap_set_dhcps_lease

Function:

Set the IP range that can be got from ESP8266 soft-AP DHCP server.

Note:

- IP range has to be in the same sub-net with ESP8266 soft-AP IP address
- This API can only be called during DHCP server disable ([wifi_softap_dhcps_stop](#))
- This configuration only take effect on next [wifi_softap_dhcps_start](#), if then [wifi_softap_dhcps_stop](#) is called; user needs to call this API to set IP range again if needed, then call [wifi_softap_dhcps_start](#) to take effect.

Prototype:

```
bool wifi_softap_set_dhcps_lease(struct dhcps_lease *please)
```

Parameter:

```
struct dhcps_lease {  
    struct ip_addr start_ip;  
    struct ip_addr end_ip;  
};
```

Return:

true: succeed
false: fail

**Example:**

```
void dhcps_lease_test(void)
{
    struct dhcps_lease dhcp_lease;
    const char* start_ip = "192.168.5.100";
    const char* end_ip = "192.168.5.105";

    dhcp_lease.start_ip.addr = ipaddr_addr(start_ip);
    dhcp_lease.end_ip.addr = ipaddr_addr(end_ip);
    wifi_softap_set_dhcps_lease(&dhcp_lease);
}

or

void dhcps_lease_test(void)
{
    struct dhcps_lease dhcp_lease;
    IP4_ADDR(&dhcp_lease.start_ip, 192, 168, 5, 100);
    IP4_ADDR(&dhcp_lease.end_ip, 192, 168, 5, 105);
    wifi_softap_set_dhcps_lease(&dhcp_lease);
}

void user_init(void)
{
    struct ip_info info;
    wifi_set_opmode(STATIONAP_MODE); //Set softAP + station mode
    wifi_softap_dhcps_stop();

    IP4_ADDR(&info.ip, 192, 168, 5, 1);
    IP4_ADDR(&info.gw, 192, 168, 5, 1);
    IP4_ADDR(&info.netmask, 255, 255, 255, 0);
    wifi_set_ip_info(SOFTAP_IF, &info);

    dhcps_lease_test();
    wifi_softap_dhcps_start();
}
```

37. wifi_softap_dhcps_status

Function: Get ESP8266 soft-AP DHCP server status.

Prototype:

```
enum dhcp_status wifi_softap_dhcps_status(void)
```

**Parameter:**`null`**Return:**

```
enum dhcp_status {  
    DHCP_STOPPED,  
    DHCP_STARTED  
};
```

38. wifi_softap_set_dhcps_offer_option

Function:

Set ESP8266 soft-AP DHCP server option.

Structure:

```
enum dhcps_offer_option{  
    OFFER_START = 0x00,  
    OFFER_ROUTER = 0x01,  
    OFFER_END  
};
```

Prototype:

```
bool wifi_softap_set_dhcps_offer_option(uint8 level, void* optarg)
```

Parameter:

```
uint8 level - OFFER_ROUTER set router option  
void* optarg - default to be enable  
bit0, 0 disable router information from ESP8266 softAP DHCP server;  
bit0, 1 enable router information from ESP8266 softAP DHCP server;
```

Return:

```
true : succeed  
false : fail
```

Example:

```
uint8 mode = 0;  
wifi_softap_set_dhcps_offer_option(OFFER_ROUTER, &mode);
```



39. wifi_set_phy_mode

Function: Set ESP8266 physical mode (802.11b/g/n).

Note: ESP8266 soft-AP only support bg.

Prototype:

```
bool wifi_set_phy_mode(enum phy_mode mode)
```

Parameter:

```
enum phy_mode mode : physical mode
enum phy_mode {
    PHY_MODE_11B = 1,
    PHY_MODE_11G = 2,
    PHY_MODE_11N = 3
};
```

Return:

```
true : succeed
false : fail
```

40. wifi_get_phy_mode

Function:

Get ESP8266 physical mode (802.11b/g/n)

Prototype:

```
enum phy_mode wifi_get_phy_mode(void)
```

Parameter:

```
null
```

Return:

```
enum phy_mode{
    PHY_MODE_11B = 1,
    PHY_MODE_11G = 2,
    PHY_MODE_11N = 3
};
```

41. wifi_get_ip_info

Function:

Get IP info of WiFi station or soft-AP interface

**Prototype:**

```
bool wifi_get_ip_info(  
    uint8 if_index,  
    struct ip_info *info  
)
```

Parameters:

`uint8 if_index` : the interface to get IP info: `0x00` for `STATION_IF`, `0x01` for `SOFTAP_IF`.
`struct ip_info *info` : pointer to get IP info of a certain interface

Return:

true: succeed
false: fail

42. wifi_set_ip_info

Function:

Set IP address of ESP8266 station or soft-AP

Note:

To set static IP, please disable DHCP first (`wifi_station_dhcpc_stop` or `wifi_softap_dhcps_stop`):

If enable static IP, DHCP will be disabled;

If enable DHCP, static IP will be disabled;

Prototype:

```
bool wifi_set_ip_info(  
    uint8 if_index,  
    struct ip_info *info  
)
```

Prototype:

```
uint8 if_index : set station IP or soft-AP IP  
#define STATION_IF      0x00  
#define SOFTAP_IF      0x01  
struct ip_info *info : IP information
```

Example:

```
struct ip_info info;  
wifi_station_dhcpc_stop();  
wifi_softap_dhcps_stop();
```



```
IP4_ADDR(&info.ip, 192, 168, 3, 200);
IP4_ADDR(&info.gw, 192, 168, 3, 1);
IP4_ADDR(&info.netmask, 255, 255, 255, 0);
wifi_set_ip_info(STATION_IF, &info);

IP4_ADDR(&info.ip, 10, 10, 10, 1);
IP4_ADDR(&info.gw, 10, 10, 10, 1);
IP4_ADDR(&info.netmask, 255, 255, 255, 0);
wifi_set_ip_info(SOFTAP_IF, &info);

wifi_softap_dhcps_start();
```

Return:

true: succeed
false: fail

43. wifi_set_macaddr

Function:

Sets MAC address

Note:

- This API can only be called in [user_init](#).
- ESP8266 soft-AP and station have different MAC address, please don't set them to be the same one.

Prototype:

```
bool wifi_set_macaddr(
    uint8 if_index,
    uint8 *macaddr
)
```

Parameter:

```
uint8 if_index : set station MAC or soft-AP mac
#define STATION_IF      0x00
#define SOFTAP_IF       0x01
uint8 *macaddr : MAC address
```

Example:

```
char sofap_mac[6] = {0x16, 0x34, 0x56, 0x78, 0x90, 0xab};
char sta_mac[6] = {0x12, 0x34, 0x56, 0x78, 0x90, 0xab};
wifi_set_macaddr(SOFTAP_IF, sofap_mac);
wifi_set_macaddr(STATION_IF, sta_mac);
```

**Return:**

true: succeed
false: fail

44. wifi_get_macaddr

Function: get MAC address

Prototype:

```
bool wifi_get_macaddr(  
    uint8 if_index,  
    uint8 *macaddr  
)
```

Parameter:

```
uint8 if_index : set station MAC or soft-AP mac  
#define STATION_IF     0x00  
#define SOFTAP_IF      0x01  
uint8 *macaddr : MAC address
```

Return:

true: succeed
false: fail

45. wifi_set_sleep_type

Function:

Sets sleep type for power saving. Set `NONE_SLEEP_T` to disable power saving.

Note: Default to be Modem sleep.

Prototype:

```
bool wifi_set_sleep_type(enum sleep_type type)
```

Parameters:

```
enum sleep_type type : sleep type
```

Return:

true: succeed
false: fail

46. wifi_get_sleep_type

Function:

Gets sleep type.

**Prototype:**

```
enum sleep_type wifi_get_sleep_type(void)
```

Parameters:

```
null
```

Return:

```
enum sleep_type {  
    NONE_SLEEP_T = 0;  
    LIGHT_SLEEP_T,  
    MODEM_SLEEP_T  
};
```

47. wifi_status_led_install

Function:

```
Installs WiFi status LED
```

Prototype:

```
void wifi_status_led_install (  
    uint8 gpio_id,  
    uint32 gpio_name,  
    uint8 gpio_func  
)
```

Parameter:

```
uint8 gpio_id    : GPIO number  
uint8 gpio_name : GPIO mux name  
uint8 gpio_func : GPIO function
```

Return:

```
null
```

Example:

```
Use GPIO0 as WiFi status LED  
#define HUMITURE_WIFI_LED_IO_MUX      PERIPHS_IO_MUX_GPIO0_U  
#define HUMITURE_WIFI_LED_IO_NUM       0  
#define HUMITURE_WIFI_LED_IO_FUNC     FUNC_GPIO0  
wifi_status_led_install(HUMITURE_WIFI_LED_IO_NUM,  
                        HUMITURE_WIFI_LED_IO_MUX, HUMITURE_WIFI_LED_IO_FUNC)
```

48. wifi_status_led_uninstall

Function: Uninstall WiFi status LED**Prototype:**

```
void wifi_status_led_uninstall ()
```

**Parameter:**

null

Return:

null

49. wifi_set_broadcast_if

Function:

Set ESP8266 send UDP broadcast from station interface or soft-AP interface, or both station and soft-AP interfaces. Default to be soft-AP.

Note:

If set broadcast interface to be station only, ESP8266 softAP DHCP server will be disable.

Prototype:

```
bool wifi_set_broadcast_if (uint8 interface)
```

Parameter:

uint8 interface : 1:station; 2:soft-AP, 3:station+soft-AP

Return:

true: succeed
false: fail

50. wifi_get_broadcast_if

Function:

Get interface which ESP8266 sent UDP broadcast from. This is usually used when you have STA + soft-AP mode to avoid ambiguity.

Prototype:

```
uint8 wifi_get_broadcast_if (void)
```

Parameter:

null

Return:

1: station
2: soft-AP
3: both station and soft-AP

51. wifi_set_event_handler_cb

Function:

Register Wi-Fi event handler

**Prototype:**

```
void wifi_set_event_handler_cb(wifi_event_handler_cb_t cb)
```

Parameter:

```
wifi_event_handler_cb_t cb : callback
```

Return:

```
none
```

Example:

```
void wifi_handle_event_cb(System_Event_t *evt)
{
    os_printf("event %x\n", evt->event);
    switch (evt->event) {
        case EVENT_STAMODE_CONNECTED:
            os_printf("connect to ssid %s, channel %d\n",
                      evt->event_info.connected.ssid,
                      evt->event_info.connected.channel);
            break;
        case EVENT_STAMODE_DISCONNECTED:
            os_printf("disconnect from ssid %s, reason %d\n",
                      evt->event_info.disconnected.ssid,
                      evt->event_info.disconnected.reason);
            break;
        case EVENT_STAMODE_AUTHMODE_CHANGE:
            os_printf("mode: %d -> %d\n",
                      evt->event_info.auth_change.old_mode,
                      evt->event_info.auth_change.new_mode);
            break;
        case EVENT_STAMODE_GOT_IP:
            os_printf("ip:" IPSTR ",mask:" IPSTR ",gw:" IPSTR ,
                      IP2STR(&evt->event_info.got_ip.ip),
                      IP2STR(&evt->event_info.got_ip.mask),
                      IP2STR(&evt->event_info.got_ip.gw));
            os_printf("\n");
            break;
        case EVENT_SOFTAPMODE_STACONNECTED:
            os_printf("station: " MACSTR "join, AID = %d\n",
                      MAC2STR(evt->event_info.sta_connected.mac),
                      evt->event_info.sta_connected.aid);
            break;
    }
}
```



```
        case EVENT_SOFTAPMODE_STADISCONNECTED:  
            os_printf("station: " MACSTR "leave, AID = %d\n",  
                      MAC2STR(evt->event_info.sta_disconnected.mac),  
                      evt->event_info.sta_disconnected.aid);  
            break;  
        default:  
            break;  
    }  
}  
  
void user_init(void)  
{  
    // TODO: add your own code here....  
    wifi_set_event_hander_cb(wifi_handle_event_cb);  
}
```

52. wifi_get_channel

Function:

Get Wi-Fi channel

Prototype:

`uint8 wifi_get_channel(void)`

Parameters:

null

Return:

Channel number

53. wifi_set_channel

Function:

Set Wi-Fi channel

NOTE:

- If set channel to be different with router's channel, ESP8266 station may disconnect from router
- Set channel in soft-AP + station mode please pay attention on appendix "["ESP8266 soft-AP and station channel configuration"](#)"

Prototype:

`bool wifi_set_channel (uint8 channel)`

Parameters:

`uint8 channel` : channel number

**Return:**

true: succeed
false: fail

54. wifi_wps_enable

Function:

Enable Wi-Fi WPS function

Note:

WPS can only be used when ESP8266 station is enabled.

Structure:

```
typedef enum wps_type {  
    WPS_TYPE_DISABLE=0,  
    WPS_TYPE_PBC,  
    WPS_TYPE_PIN,  
    WPS_TYPE_DISPLAY,  
    WPS_TYPE_MAX,  
}WPS_TYPE_t;
```

Prototype:

```
bool wifi_wps_enable(WPS_TYPE_t wps_type)
```

Parameter:

WPS_TYPE_t wps_type : WPS type, so far only `WPS_TYPE_PBC` is supported

Return:

true: succeed
false: fail

55. wifi_wps_disable

Function:

Disable Wi-Fi WPS function and release resource it taken

Prototype:

```
bool wifi_wps_disable(void)
```

Parameter:

none

Return:

true: succeed
false: fail



56. wifi_wps_start

Function:

WPS starts to work

Note:

WPS can only be used when ESP8266 station is enabled.

Prototype:

```
bool wifi_wps_start(void)
```

Parameter:

none

Return:

true: means that WPS starts to work successfully, does not mean WPS succeed.

false: fail

57. wifi_set_wps_cb

Function:

Set WPS callback, parameter of the callback is the status of WPS

Callback and parameter structure:

```
typedef void (*wps_st_cb_t)(int status);

enum wps_cb_status {
    WPS_CB_ST_SUCCESS = 0,
    WPS_CB_ST_FAILED,
    WPS_CB_ST_TIMEOUT,
};
```

Note:

- If parameter `status == WPS_CB_ST_SUCCESS` in WPS callback, it means WPS got AP's information, user can call `wifi_wps_disable` to disable WPS and release resource, then call `wifi_station_connect` to connect to target AP.
- Otherwise, it means that WPS fail, user can create a timer to retry WPS by `wifi_wps_start` after a while, or call `wifi_wps_disable` to disable WPS and release resource.

Prototype:

```
bool wifi_set_wps_cb(wps_st_cb_t cb)
```

Parameter:

`wps_st_cb_t cb` : callback

**Return:**

true: succeed
false: fail



3.6. ESP-NOW APIs

In station mode, ESP8266 supports 10 encrypt ESP-NOW peers at most, with the unencrypted peers, it can be 20 peers at most.

In soft-AP mode or soft-AP + station mode, ESP8266 supports 6 encrypt ESP-NOW peers at most, with the unencrypted peers, it can be 20 peers at most.

1. esp_now_init

Function:

ESP-NOW initialization

Prototype:

```
int esp_now_init(void)
```

Parameter:

none

Return:

0, succeed

otherwise, fail

2. esp_now_deinit

Function:

Deinitialize ESP-NOW

Prototype:

```
int esp_now_deinit(void)
```

Parameter:

none

Return:

0, succeed

otherwise, fail

3. esp_now_register_recv_cb

Function:

Register ESP-NOW receive callback

Note:

When received an ESP-NOW packet, enter receive callback:

```
typedef void (*esp_now_cb_t)(u8 *mac_addr, u8 *data, u8 len)
```



Parameters of ESP-NOW receive callback:

```
u8 *mac_addr : MAC address of the sender  
u8 *data     : data received  
u8 len       : data length
```

Prototype:

```
int esp_now_register_recv_cb(esp_now_cb_t cb)
```

Parameter:

```
esp_now_cb_t cb : receive callback
```

Return:

0, succeed

otherwise, fail

4. esp_now_unregister_recv_cb

Function:

Unregister ESP-NOW receive callback

Prototype:

```
int esp_now_unregister_recv_cb(void)
```

Parameter:

none

Return:

0, succeed

otherwise, fail

5. esp_now_send

Function:

Send ESP-NOW packet

Prototype:

```
int esp_now_send(u8 *da, u8 *data, int len)
```

Parameter:

u8 *da : Destination MAC address. If it's **NULL**, send packet to all MAC addresses recorded by ESP-NOW; otherwise, send packet to target MAC address.

u8 *data : data need to send

u8 len : data length

**Return:**

0, succeed
otherwise, fail

6. esp_now_add_peer

Function:

Add an ESP-NOW peer, store MAC address of target device into ESP-NOW MAC list.

Structure:

```
typedef enum mt_role {  
    MT_ROLE_IDLE = 0,  
    MT_ROLE_CONTROLLER,  
    MT_ROLE_SLAVE,  
    MT_ROLE_MAX,  
}
```

Prototype:

```
int esp_now_add_peer(u8 *mac_addr, u8 role, u8 channel, u8 *key, u8 key_len)
```

Parameter:

u8 *mac_addr	: MAC address of device
u8 role	: role type of device
u8 channel	: channel of device
u8 *key	: 16 bytes key which is needed for ESP-NOW communication
u8 key_len	: length of key, has to be 16 bytes now

Return:

0, succeed
otherwise, fail

7. esp_now_del_peer

Function:

Delete an ESP-NOW peer, delete MAC address of the device from ESP-NOW MAC list.

Prototype:

```
int esp_now_del_peer(u8 *mac_addr)
```

Parameter:

u8 *mac_addr : MAC address of device

**Return:**

0, succeed
otherwise, fail

8. esp_now_set_self_role

Function:

Set ESP-NOW role of device itself

Structure:

```
typedef enum mt_role {  
    MT_ROLE_IDLE = 0,  
    MT_ROLE_CONTROLLER,  
    MT_ROLE_SLAVE,  
    MT_ROLE_MAX,  
}
```

Prototype:

```
int esp_now_set_self_role(u8 role)
```

Parameter:

```
u8 role : role type
```

Return:

0, succeed
otherwise, fail

9. esp_now_get_self_role

Function:

Get ESP-NOW role of device itself

Prototype:

```
u8 esp_now_get_self_role(void)
```

Parameter:

none

Return:

role type



10. esp_now_set_peer_role

Function:

Set ESP-NOW role for a target device. If it is set multiple times, new role will cover the old one.

Structure:

```
typedef enum mt_role {  
    MT_ROLE_IDLE = 0,  
    MT_ROLE_CONTROLLER,  
    MT_ROLE_SLAVE,  
    MT_ROLE_MAX,  
}
```

Prototype:

```
int esp_now_set_peer_role(u8 *mac_addr, u8 role)
```

Parameter:

```
u8 *mac_addr      : MAC address of target device  
u8 role          : role type
```

Return:

0, succeed

otherwise, fail

11. esp_now_get_peer_role

Function:

Get ESP-NOW role of a target device

Prototype:

```
int esp_now_get_peer_role(u8 *mac_addr)
```

Parameter:

```
u8 *mac_addr      : MAC address of target device
```

Return:

MT_ROLE_CONTROLLER, role type is controller;

MT_ROLE_SLAVE, role type is slave;

otherwise, fail



12. esp_now_set_peer_key

Function:

Set ESP-NOW key for a target device. If it is set multiple times, new role will cover the old one.

Prototype:

```
int esp_now_set_peer_key(u8 *mac_addr, u8 *key, u8 key_len)
```

Parameter:

u8 *mac_addr : MAC address of target device
u8 *key : 16 bytes key which is needed for ESP-NOW communication,
if it is **NULL**, current key will be reset to be none.
u8 key_len : key length, has to be 16 bytes now

Return:

0, succeed

otherwise, fail

13. esp_now_get_peer_key

Function:

Get ESP-NOW key of a target device.

Prototype:

```
int esp_now_get_peer_key(u8 *mac_addr, u8 *key, u8 *key_len)
```

Parameter:

u8 *mac_addr : MAC address of target device
u8 *key : pointer of key, buffer size has to be 16 bytes at least
u8 *key_len : key length

Return:

0, succeed

> 0, find target device but can't get key

< 0, fail

14. esp_now_set_peer_channel

Function:

Record channel information of a ESP-NOW device.

When communicate with this device,



- call `esp_now_get_peer_channel` to get its channel first,
- then call `wifi_set_channel` to be in the same channel and do communication.

Prototype:

```
int esp_now_set_peer_channel(u8 *mac_addr, u8 channel)
```

Parameter:

`u8 *mac_addr` : MAC address of target device

`u8 channel` : channel, usually to be 1 ~ 13, some area may use channel 14

Return:

0, succeed

otherwise, fail

15. `esp_now_get_peer_channel`

Function:

Get channel information of a ESP-NOW device. ESP-NOW communication needs to be at the same channel.

Prototype:

```
int esp_now_get_peer_channel(u8 *mac_addr)
```

Parameter:

`u8 *mac_addr` : MAC address of target device

Return:

1 ~ 13 (some area may get 14), succeed

otherwise, fail

16. `esp_now_is_peer_exist`

Function:

Check if target device exists or not.

Prototype:

```
int esp_now_is_peer_exist(u8 *mac_addr)
```

Parameter:

`u8 *mac_addr` : MAC address of target device

Return:

0, device does not exist

< 0, error occur, check fail



```
> 0, device exists
```

17. esp_now_fetch_peer

Function:

Get MAC address of ESP-NOW device which is pointed now, and move the pointer to next one in ESP-NOW MAC list or move the pointer to the first one in ESP-NOW MAC list

Note:

- This API can not re-entry
- Parameter has to be `true` when you call it the first time.

Prototype:

```
u8 *esp_now_fetch_peer(bool restart)
```

Parameter:

`bool restart` : true, move pointer to the first one in ESP-NOW MAC list
false, move pointer to the next one in ESP-NOW MAC list

Return:

`NULL`, no ESP-NOW devices exist
Otherwise, MAC address of ESP-NOW device which is pointed now

18. esp_now_get_cnt_info

Function:

Get the total number of ESP-NOW devices which are associated, and the number count of encrypted devices.

Prototype:

```
int esp_now_get_cnt_info(u8 *all_cnt, u8 *encryp_cnt)
```

Parameter:

`u8 *all_cnt` : total number of ESP-NOW devices which are associated
`u8 *encryp_cnt` : number count of encrypted devices

Return:

0, succeed
otherwise, fail



3.7. Upgrade (FOTA) APIs

1. system_upgrade_userbin_check

Function:

Checks user bin

Prototype:

```
uint8 system_upgrade_userbin_check()
```

Parameter:

none

Return:

0x00 : UPGRADE_FW_BIN1, i.e. user1.bin
0x01 : UPGRADE_FW_BIN2, i.e. user2.bin

2. system_upgrade_flag_set

Function:

Sets upgrade status flag.

Note:

If you using `system_upgrade_start` to upgrade, this API need not be called.
If you using `spi_flash_write` to upgrade firmware yourself, this flag need to be set to `UPGRADE_FLAG_FINISH`, then call `system_upgrade_reboot` to reboot to run new firmware.

Prototype:

```
void system_upgrade_flag_set(uint8 flag)
```

Parameter:

uint8 flag:
#define UPGRADE_FLAG_IDLE 0x00
#define UPGRADE_FLAG_START 0x01
#define UPGRADE_FLAG_FINISH 0x02

Return:

null

3. system_upgrade_flag_check

Function:

Gets upgrade status flag.

Prototype:

```
uint8 system_upgrade_flag_check()
```

**Parameter:**

null

Return:

```
#define UPGRADE_FLAG_IDLE      0x00  
#define UPGRADE_FLAG_START     0x01  
#define UPGRADE_FLAG_FINISH    0x02
```

4. system_upgrade_start

Function:

Configures parameters and start upgrade

Prototype:

```
bool system_upgrade_start (struct upgrade_server_info *server)
```

Parameters:

```
struct upgrade_server_info *server : server related parameters
```

Return:

true: start upgrade

false: upgrade can't be started.

5. system_upgrade_reboot

Function: reboot system and use new version**Prototype:**

```
void system_upgrade_reboot (void)
```

Parameters:

none

Return:

none



3.8. Sniffer Related APIs

1. wifi_promiscuous_enable

Function:

Enable promiscuous mode for sniffer

Note:

- (1)promiscuous mode can only be enabled in station mode.
- (2)During promiscuous mode (sniffer) , ESP8266 station and soft-AP are disabled.
- (3)Before enable promiscuous mode, please call `wifi_station_disconnect` first
- (4)Don't call any other APIs during sniffer, please call
`wifi_promiscuous_enable(0)` first.

Prototype:

```
void wifi_promiscuous_enable(uint8_t promiscuous)
```

Parameter:

```
uint8_t promiscuous :  
    0: disable promiscuous;  
    1: enable promiscuous
```

Return:

null

2. wifi_promiscuous_set_mac

Function:

Set MAC address filter for sniffer.

Note:

This filter only be available in the current sniffer phase, if you disable sniffer and then enable sniffer, you need to set filter again if you need it.

Prototype:

```
void wifi_promiscuous_set_mac(const uint8_t *address)
```

Parameter:

```
const uint8_t *address : MAC address
```

Return:

null

Example:

```
char ap_mac[6] = {0x16, 0x34, 0x56, 0x78, 0x90, 0xab};
```



```
wifi_promiscuous_set_mac(ap_mac);
```

3. wifi_set_promiscuous_rx_cb

Function:

Registers an RX callback function in promiscuous mode, which will be called when data packet is received.

Prototype:

```
void wifi_set_promiscuous_rx_cb(wifi_promiscuous_cb_t cb)
```

Parameter:

```
wifi_promiscuous_cb_t cb : callback
```

Return:

```
null
```



3.9. smart config APIs

Herein we only introduce smart-config APIs, user can apply to Espressif Systems for smart-config documentation which contains more details. Please make sure the target AP is enabled before enable smart-config.

1. smartconfig_start

Function:

Start smart configuration mode, to connect ESP8266 station to AP, by sniffing for special packets from the air, containing SSID and password of desired AP. You need to broadcast the SSID and password (e.g. from mobile device or computer) with the SSID and password encoded.

Note:

- (1)This api can only be called in station mode.
- (2)During smart config, ESP8266 station and soft-AP are disabled.
- (3)Can not call `smartconfig_start` twice before it finish, please call `smartconfig_stop` first.
- (4)Don't call any other APIs during smart config, please call `smartconfig_stop` first.

Structure:

```
typedef enum {
    SC_STATUS_WAIT = 0,          // Please don't start connection in this phase
    SC_STATUS_FIND_CHANNEL,     // Start connection by APP in this phase
    SC_STATUS_GETTING_SSID_PSWD,
    SC_STATUS_LINK,
    SC_STATUS_LINK_OVER,        // Got IP, connect to AP successfully
} sc_status;
typedef enum {
    SC_TYPE_ESPTOUCH = 0,
    SC_TYPE_AIRKISS,
} sc_type;
```

Prototype:

```
bool smartconfig_start(
    sc_callback_t cb,
    uint8 log
)
```

**Parameter:**

```
sc_callback_t cb : smart config callback; executed when smart-config status changed;  
  
parameter status of this callback shows the status of smart-config:  


- if status == SC_STATUS_GETTING_SSID_PSWD, parameter void *pdata is a pointer of sc_type, means smart-config type: AirKiss or ESP-TOUCH.
- if status == SC_STATUS_LINK, parameter void *pdata is a pointer of struct station_config;
- if status == SC_STATUS_LINK_OVER, parameter void *pdata is a pointer of mobile phone's IP address, 4 bytes. This is only available in ESPTOUCH, otherwise, it is NULL.
- otherwise, parameter void *pdata is NULL.

  
uint8 log : 1: UART output logs; otherwise: UART only outputs the result.
```

Return:

```
true: succeed  
false: fail
```

Example:

```
void ICACHE_FLASH_ATTR  
  
smartconfig_done(sc_status status, void *pdata)  
{  
    switch(status) {  
        case SC_STATUS_WAIT:  
            os_printf("SC_STATUS_WAIT\n");  
            break;  
        case SC_STATUS_FIND_CHANNEL:  
            os_printf("SC_STATUS_FIND_CHANNEL\n");  
            break;  
        case SC_STATUS_GETTING_SSID_PSWD:  
            os_printf("SC_STATUS_GETTING_SSID_PSWD\n");  
            sc_type *type = pdata;  
            if (*type == SC_TYPE_ESPTOUCH) {  
                os_printf("SC_TYPE:SC_TYPE_ESPTOUCH\n");  
            } else {  
                os_printf("SC_TYPE:SC_TYPE_AIRKISS\n");  
            }  
            break;  
        case SC_STATUS_LINK:
```



```
        os_printf("SC_STATUS_LINK\n");
        struct station_config *sta_conf = pdata;
        wifi_station_set_config(sta_conf);
        wifi_station_disconnect();
        wifi_station_connect();
        break;
    case SC_STATUS_LINK_OVER:
        os_printf("SC_STATUS_LINK_OVER\n");
        if (pdata != NULL) {
            uint8 phone_ip[4] = {0};
            memcpy(phone_ip, (uint8*)pdata, 4);
            os_printf("Phone ip: %d.%d.%d.%d\n",
                      phone_ip[0], phone_ip[1], phone_ip[2], phone_ip[3]);
        }
        smartconfig_stop();
        break;
    }
}
smartconfig_start(smartconfig_done);
```

2. smartconfig_stop

Function:

stop smart config, free the buffer taken by [smartconfig_start](#).

Note:

Whether connect to AP succeed or not, this API should be called to free memory taken by [smartconfig_start](#).

Prototype:

`bool smartconfig_stop(void)`

Parameter:

null

Return:

true: succeed
false: fail



3.10. SNTP APIs

1. sntp_setserver

Function:

Set SNTP server by IP address, support 3 SNTP server at most

Prototype:

```
void sntp_setserver(unsigned char idx, ip_addr_t *addr)
```

Parameter:

`unsigned char idx` : SNTP server index, support 3 SNTP server at most (0 ~ 2) ; index 0 is the main server, index 1 and 2 are as backup.
`ip_addr_t *addr` : IP address; users need to ensure that it's a SNTP server

Return:

none

2. sntp_getserver

Function:

Get IP address of SNTP server which set by `sntp_setserver`

Prototype:

```
ip_addr_t sntp_getserver(unsigned char idx)
```

Parameter:

`unsigned char idx` : SNTP server index, support 3 SNTP server at most (0 ~ 2)

Return:

IP address

3. sntp_setservername

Function:

Set SNTP server by domain name, support 3 SNTP server at most

Prototype:

```
void sntp_setservername(unsigned char idx, char *server)
```

Parameter:

`unsigned char idx` : SNTP server index, support 3 SNTP server at most (0 ~ 2) ; index 0 is the main server, index 1 and 2 are as backup.
`char *server` : domain name; users need to ensure that it's a SNTP server

Return:

none



4. sntp_getservername

Function:

Get domain name of SNTP server which set by [sntp_setservername](#)

Prototype:

```
char * sntp_getservername(unsigned char idx)
```

Parameter:

`unsigned char idx` : SNTP server index, support 3 SNTP server at most (0 ~ 2)

Return:

domain name

5. sntp_init

Function:

SNTP initialize

Prototype:

```
void sntp_init(void)
```

Parameter:

none

Return:

none

6. sntp_stop

Function:

Stop SNTP

Prototype:

```
void sntp_stop(void)
```

Parameter:

none

Return:

none

7. sntp_get_current_timestamp

Function:

Get current timestamp from basic time (1970.01.01 00: 00: 00 GMT + 8) ,
uint:second

**Prototype:**

```
uint32 sntp_get_current_timestamp()
```

Parameter:

none

Return:

time stamp

8. sntp_get_real_time

Function:

Get real time (GMT + 8)

Prototype:

```
char* sntp_get_real_time(long t)
```

Parameter:

long t - time stamp

Return:

real time

9. sntp_set_timezone

Function:

Set time zone

Prototype:

```
bool sntp_set_timezone (sint8 timezone)
```

Note:

Before call `sntp_set_timezone`, please call `sntp_stop` first

Parameter:

`sint8 timezone` - time zone, range: -11 ~ 13

Return:

true, succeed;

false, fail

Example:

```
sntp_stop();  
if( true == sntp_set_timezone(-5) ) {
```



```
    sntp_init();  
}
```

10. sntp_get_timezone

Function:

Get time zone

Prototype:

```
sint8 sntp_get_timezone (void)
```

Parameter:

none

Return:

time zone, range: -11 ~ 13

11. SNTP Example

```
ip_addr_t *addr = (ip_addr_t *)os_zalloc(sizeof(ip_addr_t));  
  
sntp_setservername(0, "us.pool.ntp.org"); // set server 0 by domain name  
sntp_setservername(1, "ntp.sjtu.edu.cn"); // set server 1 by domain name  
ipaddr_aton("210.72.145.44", addr);  
  
sntp_setserver(2, addr); // set server 2 by IP address  
  
sntp_init();  
os_free(addr);  
  
uint32 current_stamp;  
current_stamp = sntp_get_current_timestamp();  
os_printf("sntp: %d, %s \n", current_stamp, sntp_get_real_time(current_stamp));
```



4. TCP/UDP APIs

Found in [esp_iot_sdk/include/espconn.h](#). The network APIs can be grouped into the following types:

- **General APIs:** APIs can be used for both TCP and UDP .
- **TCP APIs:** APIs that are only used for TCP.
- **UDP APIs:** APIs that are only used for UDP.
- **mDNS APIs:** APIs that related to mDNS

4.1. Generic TCP/UDP APIs

1. espconn_delete

Function:

Delete a transmission.

Note:

Corresponding creation API :

TCP: [espconn_accept](#),

UDP: [espconn_create](#)

Prototype:

```
sint8 espconn_delete(struct espconn *espconn)
```

Parameter:

`struct espconn *espconn` : corresponding connected control block structure

Return:

0 : succeed

Non-0 : error, return error code [ESPCONN_ARG](#) – illegal argument, can't find network transmission according to structure `espconn`

2. espconn_gethostbyname

Function:

DNS

**Prototype:**

```
err_t espconn_gethostbyname(  
    struct espconn *pespconn,  
    const char *hostname,  
    ip_addr_t *addr,  
    dns_found_callback found  
)
```

Parameters:

```
struct espconn *espconn : corresponding connected control block structure  
const char *hostname : domain name string pointer  
ip_addr_t *addr : IP address  
dns_found_callback found : callback
```

Return:

```
err_t : ESPCONN_OK – succeed  
       ESPCONN_INPROGRESS – error code : already connected  
       ESPCONN_ARG – error code : illegal argument, can't find network  
transmission according to structure espconn
```

Example as follows. Pls refer to source code of IoT_Demo:

```
ip_addr_t esp_server_ip;  
LOCAL void ICACHE_FLASH_ATTR  
user_esp_platform_dns_found(const char *name, ip_addr_t *ipaddr, void *arg)  
{  
    struct espconn *pespconn = (struct espconn *)arg;  
  
    if (ipaddr != NULL)  
        os_printf(user_esp_platform_dns_found %d.%d.%d/n,  
                  *((uint8 *)&ipaddr->addr), *((uint8 *)&ipaddr->addr + 1),  
                  *((uint8 *)&ipaddr->addr + 2), *((uint8 *)&ipaddr->addr + 3));  
}  
void dns_test(void) {  
    espconn_gethostbyname(pespconn, "iot.espressif.cn", &esp_server_ip,  
                         user_esp_platform_dns_found);  
}
```

3. espconn_port

Function: get void ports

Prototype:

```
uint32 espconn_port(void)
```

Parameter:

```
null
```

**Return:**

```
uint32 : id of the port you get
```

4. espconn_regist_sentcb

Function:

Register data sent function which will be called back when data are successfully sent.

Prototype:

```
sint8 espconn_regist_sentcb(  
    struct espconn *espconn,  
    espconn_sent_callback sent_cb  
)
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure
`espconn_sent_callback sent_cb` : registered callback function

Return:

0 : succeed
Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find network transmission according to structure `espconn`

5. espconn_regist_recvcb

Function:

register data receive function which will be called back when data are received

Prototype:

```
sint8 espconn_regist_recvcb(  
    struct espconn *espconn,  
    espconn_recv_callback recv_cb  
)
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure
`espconn_connect_callback connect_cb` : registered callback function

Return:

0 : succeed
Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find network transmission according to structure `espconn`



6. espconn_sent_callback

Function:

Callback after the data are sent

Prototype:

```
void espconn_sent_callback (void *arg)
```

Parameters:

`void *arg` : pointer corresponding structure `espconn`. This pointer may be different in different callbacks, please don't use this pointer directly to distinguish one from another in multiple connections, use `remote_ip` and `remote_port` in `espconn` instead.

Return:

null

7. espconn_recv_callback

Function:

callback after data are received

Prototype:

```
void espconn_recv_callback (
    void *arg,
    char *pdata,
    unsigned short len
)
```

Parameters:

`void *arg` : pointer corresponding structure `espconn`. This pointer may be different in different callbacks, please don't use this pointer directly to distinguish one from another in multiple connections, use `remote_ip` and `remote_port` in `espconn` instead.

`char *pdata` : received data entry parameters

`unsigned short len` : received data length

Return:

null

8. espconn_sent

Function:

Send data through WiFi

Note:

Please call `espconn_sent` after `espconn_sent_callback` of the pre-packet.

**Prototype:**

```
sint8 espconn_sent(  
    struct espconn *espconn,  
    uint8 *psent,  
    uint16 length  
)
```

Parameters:

```
struct espconn *espconn : corresponding connected control block structure  
uint8 *psent : sent data pointer  
uint16 length : sent data length
```

Return:

```
0 : succeed  
Non-0 : error code  
    ESPCONN_MEM - Out of memory  
    ESPCONN_ARG - illegal argument, can't find network transmission according  
    to structure espconn
```

4.2. TCP APIs

TCP APIs act only on TCP connections and do not affect nor apply to UDP connections.

1. espconn_accept

Function:

Creates a TCP server (i.e. accepts connections.)

Prototype:

```
sint8 espconn_accept(struct espconn *espconn)
```

Parameter:

```
struct espconn *espconn : corresponding connected control block structure
```

Return:

```
0 : succeed  
Non-0 : error code  
    ESPCONN_MEM - Out of memory  
    ESPCONN_ISCONN - Already connected  
    ESPCONN_ARG - illegal argument, can't find TCP connection according to  
    structure espconn
```



2. espconn_secure_accept

Function:

Creates an SSL TCP server.

Note:

- (1) Only created one SSL server is allowed, this API can be called only once, and only one SSL client is allowed to connect.
- (2) If SSL encrypted packet size is larger than ESP8266 SSL buffer size (default 2KB, set by `espconn_secure_set_size`), SSL connection will fail, will enter `espconn_reconnect_callback`
- (3) SSL related APIs named as `espconn_secure_XXX` are different from normal TCP APIs, so please don't mixed use. In SSL connection, only `espconn_secure_XXX` APIs, `espconn_regist_XXX` APIs and `espconn_port` can be used.

Prototype:

```
sint8 espconn_secure_accept(struct espconn *espconn)
```

Parameter:

`struct espconn *espconn` : corresponding connected control block structure

Return:

0 : succeed

Non-0 : error code

`ESPCONN_MEM` – Out of memory

`ESPCONN_ISCONN` – Already connected

`ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

3. espconn_regist_time

Function:

Register timeout interval of ESP8266 TCP server.

Note:

Call this API after `espconn_accept`, before listened a TCP connection.

This timeout interval is not very precise, only as reference.

If timeout is set to 0, timeout will be disable and ESP8266 TCP server will not disconnect TCP clients has stopped communication. This usage of `timeout=0`, is deprecated.

**Prototype:**

```
sint8 espconn_regist_time(  
    struct espconn *espconn,  
    uint32 interval,  
    uint8 type_flag  
)
```

Parameters:

struct espconn *espconn : corresponding connected control block structure
uint32 interval : timeout interval, unit: second, maximum: 7200 seconds
uint8 type_flag : 0, set all connections; 1, set a single connection

Return:

0 : succeed
Non-0 : error code ESPCONN_ARG – illegal argument, can't find TCP
connection according to structure espconn

4. [espconn_get_connection_info](#)

Function:

Get a connection's info in TCP multi-connection case

Prototype:

```
sint8 espconn_get_connection_info(  
    struct espconn *espconn,  
    remot_info **pcon_info,  
    uint8 typeflags  
)
```

Parameters:

struct espconn *espconn : corresponding connected control block structure
remot_info **pcon_info : connect to client info
uint8 typeflags : 0, regular server;1, ssl server

Return:

0 : succeed
Non-0 : error code ESPCONN_ARG – illegal argument, can't find TCP
connection according to structure espconn

5. [espconn_connect](#)

Function:

Connect to a TCP server (ESP8266 acting as TCP client).

Note:



If `espconn_connect` fail, returns non-0 value, there is no connection, so it won't enter any `espconn` callback.

Prototype:

```
sint8 espconn_connect(struct espconn *espconn)
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure

Return:

0 : succeed

Non-0 : error code

`ESPCONN_RTE` – Routing Problem

`ESPCONN_MEM` – Out of memory

`ESPCONN_ISCONN` – Already connected

`ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

6. `espconn_connect_callback`

Function: successful listening (ESP8266 as TCP server) or connection (ESP8266 as TCP client) callback, register by `espconn_regist_connectcb`

Prototype:

```
void espconn_connect_callback (void *arg)
```

Parameter:

`void *arg` : pointer corresponding structure `espconn`. This pointer may be different in different callbacks, please don't use this pointer directly to distinguish one from another in multiple connections, use `remote_ip` and `remote_port` in `espconn` instead.

Return:

null

7. `espconn_regist_connectcb`

Function:

Register connection function which will be called back under successful TCP connection

**Prototype:**

```
sint8 espconn_regist_connectcb(  
    struct espconn *espconn,  
    espconn_connect_callback connect_cb  
)
```

Parameters:

```
struct espconn *espconn : corresponding connected control block structure  
espconn_connect_callback connect_cb : registered callback function
```

Return:

```
0      : succeed  
Non-0  : error code ESPCONN_ARG - illegal argument, can't find TCP  
connection according to structure espconn
```

8. espconn_set_opt

Function: Set option of TCP connection

Prototype:

```
sint8 espconn_set_opt(  
    struct espconn *espconn,  
    uint8 opt  
)
```

Structure:

```
enum espconn_option{  
    ESPCONN_START = 0x00,  
    ESPCONN_REUSEADDR = 0x01,  
    ESPCONN_NODELAY = 0x02,  
    ESPCONN_COPY = 0x04,  
    ESPCONN_KEEPALIVE = 0x08,  
    ESPCONN_END  
}
```

Parameter:

```
struct espconn *espconn : corresponding connected control structure  
uint8 opt : Option of TCP connection, refer to espconn_option  
bit 0: 1: free memory after TCP disconnection happen need not wait 2  
minutes;  
bit 1: 1: disable nagle algorithm during TCP data transmission, quiken the  
data transmission.  
bit 2: 1: use 2920 bytes write buffer for the data espconn_sent sending.  
bit 3: 1: enable TCP keep alive
```

**Return:**

0 : succeed
Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

Note:

In general, we need not call this API;
If call `espconn_set_opt`, please call it in `espconn_connect_callback`.

9. `espconn_clear_opt`

Function:

Clear option of TCP connection.

Prototype:

```
sint8 espconn_clear_opt(  
    struct espconn *espconn,  
    uint8 opt  
)
```

Structure:

```
enum espconn_option{  
    ESPCONN_START = 0x00,  
    ESPCONN_REUSEADDR = 0x01,  
    ESPCONN_NODELAY = 0x02,  
    ESPCONN_COPY = 0x04,  
    ESPCONN_KEEPALIVE = 0x08,  
    ESPCONN_END  
}
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure
`uint8 opt` : option of TCP connection, refer to `espconn_option`

Return:

0 : succeed
Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

10. `espconn_set_keepalive`

Function:

Set configuration of TCP keep alive .

**Prototype:**

```
sint8 espconn_set_keepalive(struct espconn *espconn, uint8 level, void* optarg)
```

Structure:

```
enum espconn_level{  
    ESPCONN_KEEPIDLE,  
    ESPCONN_KEEPINTVL,  
    ESPCONN_KEEPCNT  
}
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure
`uint8 level` : Default to do TCP keep-alive detection every `ESPCONN_KEEPIDLE`, if there is no response, retry `ESPCONN_KEEPCNT` times every `ESPCONN_KEEPINTVL`. If still no response, considers it as TCP connection broke, goes into `espconn_reconnect_callback`.

Notice, keep alive interval is not precise, only for reference, it depends on priority.

description:

`ESPCONN_KEEPIDLE` – TCP keep-alive interval, unit: 500 millisecond
`ESPCONN_KEEPINTVL` – packet interval during TCP keep-alive, unit: 500 millisecond
`ESPCONN_KEEPCNT` – maximum packet count of TCP keep-alive

`void* optarg` : value of parameter

Return:

`0` : succeed
`Non-0` : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

Note:

In general, we need not call this API;
If needed, please call it in `espconn_connect_callback` and call `espconn_set_opt` to enable keep alive first.



11. espconn_get_keepalive

Function:

Get value of TCP keep-alive parameter

Prototype:

```
sint8 espconn_set_keepalive(struct espconn *espconn, uint8 level, void* optarg)
```

Structure:

```
enum espconn_level{  
    ESPCONN_KEEPIDLE,  
    ESPCONN_KEEPINTVL,  
    ESPCONN_KEEPCNT  
}
```

Parameter:

```
struct espconn *espconn : corresponding connected control block structure  
uint8 level :  
    ESPCONN_KEEPIDLE - TCP keep-alive interval, unit: 500 millisecond  
    ESPCONN_KEEPINTVL - packet interval during TCP keep-alive, unit: 500  
    millisecond  
    ESPCONN_KEEPCNT - maximum packet count of TCP keep-alive  
void* optarg : value of parameter
```

Return:

```
0 : succeed  
Non-0 : error code ESPCONN\_ARG - illegal argument, can't find TCP  
connection according to structure espconn
```

12. espconn_reconnect_callback

Function:

Enter this callback when error occurred, TCP connection broke. This callback
is registered by [espconn_register_reconcb](#)

Prototype:

```
void espconn_reconnect_callback (void *arg, sint8 err)
```

**Parameter:**

`void *arg` : pointer corresponding structure `espconn`. This pointer may be different in different callbacks, please don't use this pointer directly to distinguish one from another in multiple connections, use `remote_ip` and `remote_port` in `espconn` instead.

`sint8 err` : error code

`ESCONN_TIMEOUT` – Timeout
`ESPCONN_ABRT` – TCP connection aborted
`ESPCONN_RST` – TCP connection abort
`ESPCONN_CLSD` – TCP connection closed
`ESPCONN_CONN` – TCP connection
`ESPCONN_HANDSHAKE` – TCP SSL handshake fail
`ESPCONN_PROTO_MSG` – SSL application invalid

Return:

none

13. `espconn_regist_reconcb`

Function:

Register reconnect callback

Note:

`espconn_reconnect_callback` is more like a network-broken error handler; it handles errors that occurred in any phase of the connection. For instance, if `espconn_sent` fails, `espconn_reconnect_callback` will be called because the network is broken.

Prototype:

```
sint8 espconn_regist_reconcb(  
    struct espconn *espconn,  
    espconn_reconnect_callback recon_cb  
)
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure
`espconn_reconnect_callback recon_cb` : registered callback function

Return:

`0` : succeed
Non-`0` : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`



14. espconn_disconnect

Function:

disconnect a TCP connection

Prototype:

```
sint8 espconn_disconnect(struct espconn *espconn)
```

Parameters:

`struct espconn *espconn` : corresponding connected control structure

Return:

0 : succeed

Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

15. espconn_regist_disconcb

Function:

Register disconnection function which will be called back under successful TCP disconnection

Prototype:

```
sint8 espconn_regist_disconcb(  
    struct espconn *espconn,  
    espconn_connect_callback discon_cb  
)
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure
`espconn_connect_callback connect_cb` : registered callback function

Return:

0 : succeed

Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

16. espconn_regist_write_finish

Function:

Register a callback which will be called when all sending data is completely write into write buffer or sent. Need to call `espconn_set_opt` to enable write-buffer first.

Note:



write-buffer is used to keep TCP data that waiting for sending, users can enable it by `espconn_set_opt`. Then users can call `espconn_sent` to send next packet in `write_finish_callback` instead of `espconn_sent_callback`.

Prototype:

```
sint8 espconn_regist_write_finish (
    struct espconn *espconn,
    espconn_connect_callback write_finish_fn
)
```

Parameters:

```
struct espconn *espconn : corresponding connected control block structure
espconn_connect_callback write_finish_fn : registered callback function
```

Return:

```
0 : succeed
Non-0 : error code ESPCONN_ARG – illegal argument, can't find TCP
connection according to structure espconn
```

17. `espconn_secure_set_size`

Function:

Set buffer size of encrypted data (SSL)

Note:

Buffer size default to be 2Kbytes. If need to change, please call this API before `espconn_secure_accept` (ESP8266 as TCP SSL server) or `espconn_secure_connect` (ESP8266 as TCP SSL client)

Prototype:

```
bool espconn_secure_set_size (uint8 level, uint16 size)
```

Parameters:

```
uint8 level : set buffer for ESP8266 SSL server/client:
```

```
    0x01  SSL client;
    0x02  SSL server;
    0x03  both SSL client and SSL server
```

```
uint16 size : buffer size, range: 1 ~ 8192, unit: byte, default to be 2048
```

Return:

```
true : succeed
false : fail
```



18. espconn_secure_get_size

Function:

Get buffer size of encrypted data (SSL)

Prototype:

```
sint16 espconn_secure_get_size (uint8 level)
```

Parameters:

`uint8 level` : buffer for ESP8266 SSL server/client:

`0x01` SSL client;

`0x02` SSL server;

`0x03` both SSL client and SSL server

Return:

buffer size

19. espconn_secure_connect

Function:

Secure connect (SSL) to a TCP server (ESP8266 is acting as TCP client.)

Note:

- If `espconn_connect` fail, returns non-0 value, there is no connection, so it won't enter any `espconn` callback.
- Only one connection is allowed when ESP8266 as SSL client, this API can be called only once, or call `espconn_secure_disconnect` to disconnect first, then call this API to create another SSL connection.
- If SSL encrypted packet size is larger than ESP8266 SSL buffer size (default 2KB, set by `espconn_secure_set_size`), SSL connection will fail, will enter `espconn_reconnect_callback`
- SSL related APIs named as `espconn_secure_XXX` are different from normal TCP APIs, so please don't mixed use. In SSL connection, only `espconn_secure_XXX` APIs, `espconn_register_XXX` APIs and `espconn_port` can be used.

Prototype:

```
sint8 espconn_secure_connect (struct espconn *espconn)
```

Parameters:

`struct espconn *espconn` : corresponding connected control block structure

Return:

`0` : succeed

Non-0 : error code



```
ESPCONN_MEM - Out of memory  
ESPCONN_ISCONN - Already connected  
ESPCONN_ARG - illegal argument, can't find TCP connection  
according to structure espconn
```

20. espconn_secure_sent

Function: send encrypted data (SSL)

Note:

Please call `espconn_secure_sent` after `espconn_sent_callback` of the pre-packet.

Prototype:

```
sint8 espconn_secure_sent (  
    struct espconn *espconn,  
    uint8 *psent,  
    uint16 length  
)
```

Parameters:

```
struct espconn *espconn : corresponding connected control block structure  
uint8 *psent : sent data pointer  
uint16 length : sent data length
```

Return:

```
0      : succeed  
Non-0  : error code ESPCONN_ARG - illegal argument, can't find TCP  
connection according to structure espconn
```

21. espconn_secure_disconnect

Function: secure TCP disconnection(SSL)

Prototype:

```
sint8 espconn_secure_disconnect(struct espconn *espconn)
```

Parameters:

```
struct espconn *espconn : corresponding connected control block structure
```

Return:

```
0      : succeed  
Non-0  : error code ESPCONN_ARG - illegal argument, can't find TCP  
connection according to structure espconn
```



22. espconn_secure_ca_disable

Function:

Disable SSL CA (certificate authenticate) function

Note:

- CA function is disabled by default, more details in document "ESP8266_SDK_SSL_User_Manual"
- If user want to call this API, please call it before [espconn_secure_accept](#) (ESP8266 as TCP SSL server) or [espconn_secure_connect](#) (ESP8266 as TCP SSL client)

Prototype:

```
bool espconn_secure_ca_disable (uint8 level)
```

Parameter:

```
uint8 level : set configuration for ESP8266 SSL server/client:  
              0x01  SSL client;  
              0x02  SSL server;  
              0x03  both SSL client and SSL server
```

Return:

```
true      : succeed  
false     : fail
```

23. espconn_secure_ca_enable

Function:

Enable SSL CA (certificate authenticate) function

Note:

- CA function is disabled by default, more details in document "ESP8266_SDK_SSL_User_Manual"
- If user want to call this API, please call it before [espconn_secure_accept](#) (ESP8266 as TCP SSL server) or [espconn_secure_connect](#) (ESP8266 as TCP SSL client)

Prototype:

```
bool espconn_secure_ca_enable (uint8 level, uint16 flash_sector)
```

Parameter:

```
uint8 level : set configuration for ESP8266 SSL server/client:  
              0x01  SSL client;
```



```
0x02 SSL server;  
0x03 both SSL client and SSL server  
uint16 flash_sector : flash sector in which CA (esp_ca_cert.bin) is  
downloaded. For example, flash_sector is 0x3B, then esp_ca_cert.bin need to  
download into flash 0x3B000
```

Return:

```
true : succeed  
false : fail
```

24. `espconn_tcp_get_max_con`

Function:

Get maximum number of how many TCP connection is allowed.

Prototype:

```
uint8 espconn_tcp_get_max_con(void)
```

Parameter:

null

Return:

Maximum number of how many TCP connection is allowed.

25. `espconn_tcp_set_max_con`

Function:

Set the maximum number of how many TCP connection is allowed.

Prototype:

```
sint8 espconn_tcp_set_max_con(uint8 num)
```

Parameter:

`uint8 num` : Maximum number of how many TCP connection is allowed.

Return:

0 : succeed

Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find TCP
connection according to structure `espconn`

26. `espconn_tcp_get_max_con_allow`

Function:

Get the maximum number of TCP clients which are allowed to connect to
ESP8266 TCP server.

**Prototype:**

```
sint8 espconn_tcp_get_max_con_allow(struct espconn *espconn)
```

Parameter:

```
struct espconn *espconn : corresponding connected control structure
```

Return:

> 0 : Maximum number of TCP clients which are allowed.

< 0 : error code [ESPCONN_ARG](#) – illegal argument, can't find TCP connection according to structure `espconn`

27. [espconn_tcp_set_max_con_allow](#)

Function:

Set the maximum number of TCP clients allowed to connect to ESP8266 TCP server.

Prototype:

```
sint8 espconn_tcp_set_max_con_allow(struct espconn *espconn, uint8 num)
```

Parameter:

```
struct espconn *espconn : corresponding connected control structure  
uint8 num : Maximum number of TCP clients which are allowed.
```

Return:

0 : succeed

Non-0 : error code [ESPCONN_ARG](#) – illegal argument, can't find TCP connection according to structure `espconn`

28. [espconn_recv_hold](#)

Function:

Puts in a request to block the TCP receive function.

Note:

The function does not act immediately; we recommend calling it while reserving 5*1460 bytes of memory.

This API can be called more than once.

Prototype:

```
sint8 espconn_recv_hold(struct espconn *espconn)
```

Parameter:

```
struct espconn *espconn : corresponding connected control structure
```

**Return:**

0 : succeed
Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

29. `espconn_recv_unhold`

Function:

Unblock TCP receiving data (i.e. undo `espconn_recv_hold`).

Note:

This API takes effect immediately.

Prototype:

```
sint8 espconn_recv_unhold(struct espconn *espconn)
```

Parameter:

`struct espconn *espconn` : corresponding connected control structure

Return:

0 : succeed
Non-0 : error code `ESPCONN_ARG` – illegal argument, can't find TCP connection according to structure `espconn`

4.3. UDP APIs

1. `espconn_create`

Function: create UDP transmission.

Prototype:

```
sint8 espconn_create(struct espconn *espconn)
```

Parameter:

`struct espconn *espconn` : corresponding connected control block structure

Return:

0 : succeed
Non-0 : error code

`ESPCONN_ISCONN` – Already connected

`ESPCONN_MEM` – Out of memory

`ESPCONN_ARG` – illegal argument, can't find UDP transmission according to structure `espconn`



2. espconn_igmp_join

Function:

Join a multicast group

Note:

This API can only be called after ESP8266 station connected to router.

Prototype:

```
sint8 espconn_igmp_join(ip_addr_t *host_ip, ip_addr_t *multicast_ip)
```

Parameters:

```
ip_addr_t *host_ip : IP of host  
ip_addr_t *multicast_ip : IP of multicast group
```

Return:

```
0 : succeed  
Non-0 : error code ESPCONN\_MEM – Out of memory
```

3. espconn_igmp_leave

Function:

Quit a multicast group

Prototype:

```
sint8 espconn_igmp_leave(ip_addr_t *host_ip, ip_addr_t *multicast_ip)
```

Parameters:

```
ip_addr_t *host_ip : IP of host  
ip_addr_t *multicast_ip : IP of multicast group
```

Return:

```
0 : succeed  
Non-0 : error code ESPCONN\_MEM – Out of memory
```

4. espconn_dns_setserver

Function:

Set default DNS server. Two DNS server is allowed to be set.

Note:

Only if ESP8266 DHCP client is disabled ([wifi_station_dhcpc_stop](#)), this API can be used

Prototype:

```
void espconn_dns_setserver(char numdns, ip_addr_t *dnsserver)
```

**Parameter:**

```
char numdns      : DNS server ID, 0 or 1  
ip_addr_t *dnsserver : DNS server IP
```

Return:

```
none
```

4.4. mDNS APIs

1. espconn_mdns_init

Function:

```
mDNS initialization
```

Note:

- (1) Only ESP8266 station support mDNS, please get IP address of ESP8266 station first, then call this API to initial mDNS;
- (2) `txt_data` has to be set as “`key = value`”, as **Example**;

Structure:

```
struct mdns_info{  
    char *host_name;  
    char *server_name;  
    uint16 server_port;  
    unsigned long ipAddress;  
    char *txt_data[10];  
};
```

Prototype:

```
void espconn_mdns_init(struct mdns_info *info)
```

Parameter:

```
struct mdns_info *info : mdns information
```

Return:

```
none
```

Example:

```
struct mdns_info *info = (struct mdns_info *)os_zalloc(sizeof(struct  
mdns_info));  
info->host_name = "espressif";
```



```
info->ipAddr = station_ipconfig.ip.addr; //ESP8266 station IP  
info->server_name = "iot";  
info->server_port = 8080;  
info->txt_data[0] = "version = now";  
info->txt_data[1] = "user1 = data1";  
info->txt_data[2] = "user2 = data2";  
espconn_mdns_init(info);
```

2. espconn_mdns_close

Function:

close mDNS, corresponding creation API : `espconn_mdns_init`

Prototype:

```
void espconn_mdns_close(void)
```

Parameter:

none

Return:

none

3. espconn_mdns_server_register

Function:

register mDNS server

Prototype:

```
void espconn_mdns_server_register(void)
```

Parameter:

none

Return:

none

4. espconn_mdns_server_unregister

Function:

unregister mDNS server

Prototype:

```
void espconn_mdns_server_unregister(void)
```

**Parameter:**

none

Return:

none

5. espconn_mdns_get_servername

Function:

Get mDNS server name

Prototype:

```
char* espconn_mdns_get_servername(void)
```

Parameter:

none

Return:

server name

6. espconn_mdns_set_servername

Function:

Set mDNS server name

Prototype:

```
void espconn_mdns_set_servername(const char *name)
```

Parameter:

const char *name – server name

Return:

none

7. espconn_mdns_set_hostname

Function:

Set mDNS host name

Prototype:

```
void espconn_mdns_set_hostname(char *name)
```

Parameter:

char *name – host name

Return:

none



8. espconn_mdns_get_hostname

Function:

Get mDNS host name

Prototype:

```
char* espconn_mdns_get_hostname(void)
```

Parameter:

none

Return:

host name

9. espconn_mdns_disable

Function:

Disable mDNS , corresponding creation API : `espconn_mdns_enable`

Prototype:

```
void espconn_mdns_disable(void)
```

Parameter:

none

Return:

none

10. espconn_mdns_enable

Function:

Enable mDNS

Prototype:

```
void espconn_mdns_enable(void)
```

Parameter:

none

Return:

none



5. Application Related

5.1. AT APIs

for AT APIs examples, refer to [esp_iot_sdk/examples/at/user/user_main.c](https://github.com/espressif/esp-iot-sdk/tree/master/examples/at/user/user_main.c).

1. at_response_ok

Function:

Output OK to AT Port (UART0)

Prototype:

```
void at_response_ok(void)
```

Parameter:

null

Return:

null

2. at_response_error

Function:

output ERROR to AT Port (UART0)

Prototype:

```
void at_response_error(void)
```

Parameter:

null

Return:

null

3. at_cmd_array_regist

Function:

register user-define AT commands.

Can be called only once to register all user-define AT commands.

Prototype:

```
void at_cmd_array_regist (
    at_function * custom_at_cmd_arrar,
    uint32 cmd_num
)
```

**Parameter:**

`at_function * custom_at_cmd_arrar` : Array of user-define AT commands
`uint32 cmd_num` : Number counts of user-define AT commands

Return:

`null`

Example:

refer to [esp_iot_sdk/examples/at/user/user_main.c](#)

4. at_get_next_int_dec

Function:

parse int from AT command

Prototype:

`bool at_get_next_int_dec (char **p_src,int* result,int* err)`

Parameter:

`char **p_src` : *`p_src` is the AT command that need to be parsed
`int* result` : int number parsed from the AT command
`int* err` : 1: no number is found; 3: only '-' is found.

Return:

`true`: parser succeeds (NOTE: if no number is found, it will return True, but returns error code 1)
`false`: parser is unable to parse string; some probable causes are: int number more than 10 bytes; string contains termination characters '/r'; string contains only '-'.

Example:

refer to [esp_iot_sdk/examples/at/user/user_main.c](#)

5. at_data_str_copy

Function: parse string from AT command**Prototype:**

`int32 at_data_str_copy (char * p_dest, char ** p_src,int32 max_len)`

Parameter:

`char * p_dest` : string parsed from the AT command
`char ** p_src` : *`p_src` is the AT command that need to be parsed
`int32 max_len` : max string length that allowed

**Return:**

length of string:
>=0: succeed and returns the length of the string
<0 : fail and returns -1

Example:

refer to [esp_iot_sdk/examples/at/user/user_main.c](#)

6. at_init

Function:

AT initialize

Prototype:

`void at_init (void)`

Parameter:

null

Return:

null

Example:

refer to [esp_iot_sdk/examples/at/user/user_main.c](#)

7. at_port_print

Function:

output string to AT PORT(UART0)

Prototype:

`void at_port_print(const char *str)`

Parameter:

`const char *str` : string that need to output

Return:

null

Example:

refer to [esp_iot_sdk/examples/at/user/user_main.c](#)

8. at_set_custom_info

Function:

User-define version info of AT which can be got by AT+GMR.

Prototype:

`void at_set_custom_info (char *info)`

**Parameter:**

```
char *info : version info
```

Return:

```
null
```

9. at_enter_special_state**Function:**

Enter processing state. In processing state, AT core will return `busy` for any further AT commands.

Prototype:

```
void at_enter_special_state (void)
```

Parameter:

```
null
```

Return:

```
null
```

10. at_leave_special_state**Function:**

Exit from AT processing state.

Prototype:

```
void at_leave_special_state (void)
```

Parameter:

```
null
```

Return:

```
null
```

11. at_get_version**Function:**

Get Espressif AT lib version.

Prototype:

```
uint32 at_get_version (void)
```

Parameter:

```
null
```

Return:

Espressif AT lib version



12. at_register_uart_rx_intr

Function:

Set UART0 to be used by user or AT commands.

Note:

This API can be called multiple times.

Running AT, UART0 default to be used by AT commands.

Prototype:

```
void at_register_uart_rx_intr(at_custom_uart_rx_intr rx_func)
```

Parameter:

`at_custom_uart_rx_intr` : register a UART0 RX interrupt handler so that
UART0 can be used by the customer, while if it's NULL, UART0 is assigned to
AT commands.

Return:

null

Example:

```
void user_uart_rx_intr(uint8* data, int32 len)
{
    // UART0 rx for user
    os_printf("len=%d \r\n", len);
    os_printf(data);

    // change UART0 for AT
    at_register_uart_rx_intr(NULL);
}

void user_init(void){ at_register_uart_rx_intr(user_uart_rx_intr); }
```

13. at_response

Function:

Set AT response

Note:

`at_response` outputs from UART0 TX by default which is same as `at_port_print`.
But if called `at_register_response_func`, the string of `at_response` will be
the parameter of `response_func`, users can define their own behavior.

Prototype:

```
void at_response (const char *str)
```

**Parameter:**

```
const char *str : string
```

Return:

```
none
```

14. at_register_response_func

Function:

Register callback of `at_response` for user-define response. After called `at_register_response_func`, the string of `at_response` will be the parameter of `response_func`, users can define their own behavior.

Prototype:

```
void at_register_response_func (at_custom_response_func_type response_func)
```

Parameter:

```
at_custom_response_func_type : callback of at_response
```

Return:

```
none
```



5.2. Related JSON APIs

Found in : [esp_iot_sdk/include/json/jsonparse.h](#) & [jsontree.h](#)

1. jsonparse_setup

```
Function:
    json initialize parsing

Prototype:
    void jsonparse_setup(
        struct jsonparse_state *state,
        const char *json,
        int len
    )

Parameters:
    struct jsonparse_state *state : json parsing pointer
    const char *json : json parsing character string
    int len : character string length

Return:
    null
```

2. jsonparse_next

```
Function:
    Returns jsonparse next object

Prototype:
    int jsonparse_next(struct jsonparse_state *state)

Parameters:
    struct jsonparse_state *state : json parsing pointer

Return:
    int : parsing result
```

3. jsonparse_copy_value

```
Function:
    Copies current parsing character string to a certain buffer
```

**Prototype:**

```
int jsonparse_copy_value(  
    struct jsonparse_state *state,  
    char *str,  
    int size  
)
```

Parameters:

```
struct jsonparse_state *state : json parsing pointer  
char *str : buffer pointer  
int size : buffer size
```

Return:

```
int : copy result
```

4. jsonparse_get_value_as_int

Function:

Parses json to get integer

Prototype:

```
int jsonparse_get_value_as_int(struct jsonparse_state *state)
```

Parameters:

```
struct jsonparse_state *state : json parsing pointer
```

Return:

```
int : parsing result
```

5. jsonparse_get_value_as_long

Function:

Parses json to get long integer

Prototype:

```
long jsonparse_get_value_as_long(struct jsonparse_state *state)
```

Parameters:

```
struct jsonparse_state *state : json parsing pointer
```

Return:

```
long : parsing result
```

6. jsonparse_get_len

Function:

Gets parsed json length

**Prototype:**

```
int jsonparse_get_value_len(struct jsonparse_state *state)
```

Parameters:

```
struct jsonparse_state *state : json parsing pointer
```

Return:

```
int : parsed jason length
```

7. jsonparse_get_value_as_type

Function:

```
Parses json data type
```

Prototype:

```
int jsonparse_get_value_as_type(struct jsonparse_state *state)
```

Parameters:

```
struct jsonparse_state *state : json parsing pointer
```

Return:

```
int : parsed json data type
```

8. jsonparse_strcmp_value

Function:

```
Compares parsed json and certain character string
```

Prototype:

```
int jsonparse_strcmp_value(struct jsonparse_state *state, const char *str)
```

Parameters:

```
struct jsonparse_state *state : json parsing pointer
```

```
const char *str : character buffer
```

Return:

```
int : comparison result
```

9. jsontree_set_up

Function:

```
Creates json data tree
```

**Prototype:**

```
void jsontree_setup(  
    struct jsontree_context *js_ctx,  
    struct jsontree_value *root,  
    int (*putchar)(int)  
)
```

Parameters:

```
struct jsontree_context *js_ctx : json tree element pointer  
struct jsontree_value *root : root element pointer  
int (*putchar)(int) : input function
```

Return:

```
null
```

10. jsontree_reset

Function:

```
Resets json tree
```

Prototype:

```
void jsontree_reset(struct jsontree_context *js_ctx)
```

Parameters:

```
struct jsontree_context *js_ctx : json data tree pointer
```

Return:

```
null
```

11. jsontree_path_name

Function:

```
get json tree parameters
```

Prototype:

```
const char *jsontree_path_name(  
    const struct jsontree_cotext *js_ctx,  
    int depth  
)
```

Parameters:

```
struct jsontree_context *js_ctx : json tree pointer  
int depth : json tree depth
```

Return:

```
char* : parameter pointer
```



12. jsontree_write_int

Function:

write integer to json tree

Prototype:

```
void jsontree_write_int(  
    const struct jsontree_context *js_ctx,  
    int value  
)
```

Parameters:

```
struct jsontree_context *js_ctx : json tree pointer  
int value : integer value
```

Return:

null

13. jsontree_write_int_array

Function:

Writes integer array to json tree

Prototype:

```
void jsontree_write_int_array(  
    const struct jsontree_context *js_ctx,  
    const int *text,  
    uint32 length  
)
```

Parameters:

```
struct jsontree_context *js_ctx : json tree pointer  
int *text : array entry address  
uint32 length : array length
```

Return:

null

14. jsontree_write_string

Function:

Writes string to json tree

**Prototype:**

```
void jsontree_write_string(  
    const struct jsontree_context *js_ctx,  
    const char *text  
)
```

Parameters:

```
struct jsontree_context *js_ctx : json tree pointer  
const char* text : character string pointer
```

Return:

```
null
```

15. jsontree_print_next

Function:

```
json tree depth
```

Prototype:

```
int jsontree_print_next(struct jsontree_context *js_ctx)
```

Parameters:

```
struct jsontree_context *js_ctx : json tree pointer
```

Return:

```
int : json tree depth
```

16. jsontree_find_next

Function:

```
find json tree element
```

Prototype:

```
struct jsontree_value *jsontree_find_next(  
    struct jsontree_context *js_ctx,  
    int type  
)
```

Parameters:

```
struct jsontree_context *js_ctx : json tree pointer  
int : type
```

Return:

```
struct jsontree_value * : json tree element pointer
```



6. Definitions & Structures

6.1. Timer

```
typedef void ETSTimerFunc(void *timer_arg);

typedef struct _ETSTIMER_ {
    struct _ETSTIMER_ *timer_next;
    uint32_t timer_expire;
    uint32_t timer_period;
    ETSTimerFunc *timer_func;
    void *timer_arg;
} ETSTimer;
```

6.2. WiFi Related Structures

1. Station Related

```
struct station_config {
    uint8 ssid[32];
    uint8 password[64];
    uint8 bssid_set;
    uint8 bssid[6];
};
```

Note:

BSSID as MAC address of AP, will be used when several APs have the same SSID.

If `station_config.bssid_set==1`, `station_config.bssid` has to be set, otherwise, the connection will fail.

In general, `station_config.bssid_set` need to be 0.

2. soft-AP related

```
typedef enum _auth_mode {
    AUTH_OPEN = 0,
    AUTH_WEP,
    AUTH_WPA_PSK,
    AUTH_WPA2_PSK,
    AUTH_WPA_WPA2_PSK
} AUTH_MODE;

struct softap_config {
```



```
    uint8 ssid[32];
    uint8 password[64];
    uint8 ssid_len;
    uint8 channel;          // support 1 ~ 13
    uint8 authmode;         // Don't support AUTH_WEP in soft-AP mode
    uint8 ssid_hidden;      // default 0
    uint8 max_connection;   // default 4, max 4
    uint16 beacon_interval; // 100 ~ 60000 ms, default 100
};

Note:
```

If `softap_config.ssid_len==0`, check ssid till find a termination characters;
otherwise, it depends on `softap_config.ssid_len`.

3. scan related

```
struct scan_config {
    uint8 *ssid;
    uint8 *bssid;
    uint8 channel;
    uint8 show_hidden; // Scan APs which are hiding their SSID or not.
};

struct bss_info {
    STAILQ_ENTRY(bss_info) next;
    u8 bssid[6];
    u8 ssid[32];
    u8 channel;
    s8 rssi;
    u8 authmode;
    uint8 is_hidden; // SSID of current AP is hidden or not.
    sint16 freq_offset; // AP's frequency offset
};
typedef void (* scan_done_cb_t)(void *arg, STATUS status);
```

4. WiFi event related structure

```
enum {
    EVENT_STAMODE_CONNECTED = 0,
    EVENT_STAMODE_DISCONNECTED,
    EVENT_STAMODE_AUTHMODE_CHANGE,
    EVENT_STAMODE_GOT_IP,
```



```
EVENT_SOFTAPMODE_STACONNECTED,
EVENT_SOFTAPMODE_STADISCONNECTED,
EVENT_MAX
};

enum {
    REASON_UNSPECIFIED          = 1,
    REASON_AUTH_EXPIRE          = 2,
    REASON_AUTH_LEAVE            = 3,
    REASON_ASSOC_EXPIRE          = 4,
    REASON_ASSOC_TOOMANY         = 5,
    REASON_NOT_AUTHED           = 6,
    REASON_NOT_ASSOCED           = 7,
    REASON_ASSOC_LEAVE           = 8,
    REASON_ASSOC_NOT_AUTHED      = 9,
    REASON_DISASSOC_PWRCAP_BAD   = 10, /* 11h */
    REASON_DISASSOC_SUPCHAN_BAD  = 11, /* 11h */
    REASON_IE_INVALID            = 13, /* 11i */
    REASON_MIC_FAILURE           = 14, /* 11i */
    REASON_4WAY_HANDSHAKE_TIMEOUT = 15, /* 11i */
    REASON_GROUP_KEY_UPDATE_TIMEOUT = 16, /* 11i */
    REASON_IE_IN_4WAY_DIFFERS     = 17, /* 11i */
    REASON_GROUP_CIPHER_INVALID   = 18, /* 11i */
    REASON_PAIRWISE_CIPHER_INVALID = 19, /* 11i */
    REASON_AKMP_INVALID           = 20, /* 11i */
    REASON_UNSUPP_RSN_IE_VERSION  = 21, /* 11i */
    REASON_INVALID_RSN_IE_CAP     = 22, /* 11i */
    REASON_802_1X_AUTH_FAILED      = 23, /* 11i */
    REASON_CIPHER_SUITE_REJECTED   = 24, /* 11i */

    REASON_BEACON_TIMEOUT         = 200,
    REASON_NO_AP_FOUND             = 201,
};

typedef struct {
    uint8 ssid[32];
    uint8 ssid_len;
    uint8 bssid[6];
    uint8 channel;
```



```
    } Event_StaMode_Connected_t;

    typedef struct {
        uint8 ssid[32];
        uint8 ssid_len;
        uint8 bssid[6];
        uint8 reason;
    } Event_StaMode_Disconnected_t;

    typedef struct {
        uint8 old_mode;
        uint8 new_mode;
    } Event_StaMode_AuthMode_Change_t;

    typedef struct {
        struct ip_addr ip;
        struct ip_addr mask;
        struct ip_addr gw;
    } Event_StaMode_Got_IP_t;

    typedef struct {
        uint8 mac[6];
        uint8 aid;
    } Event_SoftAPMode_StaConnected_t;

    typedef struct {
        uint8 mac[6];
        uint8 aid;
    } Event_SoftAPMode_StaDisconnected_t;

    typedef union {
        Event_StaMode_Connected_t          connected;
        Event_StaMode_Disconnected_t       disconnected;
        Event_StaMode_AuthMode_Change_t   auth_change;
        Event_StaMode_Got_IP_t            got_ip;
        Event_SoftAPMode_StaConnected_t   sta_connected;
        Event_SoftAPMode_StaDisconnected_t sta_disconnected;
    } Event_Info_u;
```



```
typedef struct _esp_event {
    uint32 event;
    Event_Info_u event_info;
} System_Event_t;
```

5. smart config structure

```
typedef enum {
    SC_STATUS_WAIT = 0,           // Please don't start connection in this phase
    SC_STATUS_FIND_CHANNEL,      // Start connection by APP in this phase
    SC_STATUS_GETTING_SSID_PSWD,
    SC_STATUS_LINK,
    SC_STATUS_LINK_OVER,         // Got IP, connect to AP successfully
} sc_status;
typedef enum {
    SC_TYPE_ESPTOUCH = 0,
    SC_TYPE_AIRKISS,
} sc_type;
```

6.3. JSON Related Structure

1. json structure

```
struct jsontree_value {
    uint8_t type;
};

struct jsontree_pair {
    const char *name;
    struct jsontree_value *value;
};

struct jsontree_context {
    struct jsontree_value *values[JSONTREE_MAX_DEPTH];
    uint16_t index[JSONTREE_MAX_DEPTH];
    int (* putchar)(int);
    uint8_t depth;
    uint8_t path;
    int callback_state;
};
```



```
struct jsontree_callback {
    uint8_t type;
    int (* output)(struct jsontree_context *js_ctx);
    int (* set)(struct jsontree_context *js_ctx,
                struct jsonparse_state *parser);
};

struct jsontree_object {
    uint8_t type;
    uint8_t count;
    struct jsontree_pair *pairs;
};

struct jsontree_array {
    uint8_t type;
    uint8_t count;
    struct jsontree_value **values;
};

struct jsonparse_state {
    const char *json;
    int pos;
    int len;
    int depth;
    int vstart;
    int vlen;
    char vtype;
    char error;
    char stack[JSONPARSE_MAX_DEPTH];
};
```

2. json macro definition

```
#define JSONTREE_OBJECT(name, ...) /  
static struct jsontree_pair jsontree_pair_##name[] = {__VA_ARGS__}; /  
static struct jsontree_object name = { /  
    JSON_TYPE_OBJECT, /  
    sizeof(jsontree_pair_##name)/sizeof(struct jsontree_pair), /  
    jsontree_pair_##name }
```



```
#define JSONTREE_PAIR_ARRAY(value) (struct jsontree_value_*)(value)
#define JSONTREE_ARRAY(name, ...) \
    static struct jsontree_value_* jsontree_value_##name[] = {__VA_ARGS__}; \
    static struct jsontree_array name = { \
        JSON_TYPE_ARRAY, \
        sizeof(jsontree_value_##name)/sizeof(struct jsontree_value_*), \
        jsontree_value_##name }
```

6.4. espconn parameters

1. callback function

```
/** callback prototype to inform about events for a espconn */
typedef void (*espconn_recv_callback)(void *arg, char *pdata, unsigned short len);
typedef void (*espconn_callback)(void *arg, char *pdata, unsigned short len);
typedef void (*espconn_connect_callback)(void *arg);
```

2. espconn

```
typedef void* espconn_handle;
typedef struct _esp_tcp {
    int remote_port;
    int local_port;
    uint8 local_ip[4];
    uint8 remote_ip[4];
    espconn_connect_callback connect_callback;
    espconn_reconnect_callback reconnect_callback;
    espconn_connect_callback disconnect_callback;
    espconn_connect_callback write_finish_fn;
} esp_tcp;

typedef struct _esp_udp {
    int remote_port;
    int local_port;
    uint8 local_ip[4];
    uint8 remote_ip[4];
} esp_udp;
```



```
/** Protocol family and type of the espconn */
enum espconn_type {
    ESPCONN_INVALID      = 0,
    /* ESPCONN_TCP Group */
    ESPCONN_TCP          = 0x10,
    /* ESPCONN_UDP Group */
    ESPCONN_UDP          = 0x20,
};

/** Current state of the espconn. Non-TCP espconn are always in state
ESPCONN_NONE! */
enum espconn_state {
    ESPCONN_NONE,
    ESPCONN_WAIT,
    ESPCONN_LISTEN,
    ESPCONN_CONNECT,
    ESPCONN_WRITE,
    ESPCONN_READ,
    ESPCONN_CLOSE
};

enum espconn_option{
    ESPCONN_START = 0x00,
    ESPCONN_REUSEADDR = 0x01,
    ESPCONN_NODELAY = 0x02,
    ESPCONN_COPY = 0x04,
    ESPCONN_KEEPALIVE = 0x08,
    ESPCONN_END
}

enum espconn_level{
    ESPCONN_KEEPIDLE,
    ESPCONN_KEEPINTVL,
    ESPCONN_KEEPCNT
}
/** A espconn descriptor */
struct espconn {
    /** type of the espconn (TCP, UDP) */
    enum espconn_type type;
```



```
/** current state of the espconn */
enum espconn_state state;
union {
    esp_tcp *tcp;
    esp_udp *udp;
} proto;
/** A callback function that is informed about events for this espconn */
espconn_recv_callback recv_callback;
espconn_sent_callback sent_callback;
uint8 link_cnt;
void *reverse; // reversed for customer use
};
```

6.5. interrupt related definition

```
/* interrupt related */

#define ETS_SPI_INUM      2
#define ETS_GPIO_INUM     4
#define ETS_UART_INUM     5
#define ETS_UART1_INUM    5
#define ETS_FRC_TIMER1_INUM 9

/* disable all interrupts */
#define ETS_INTR_LOCK()          ets_intr_lock()
/* enable all interrupts */
#define ETS_INTR_UNLOCK()        ets_intr_unlock()

/* register interrupt handler of frc timer1 */
#define ETS_FRC_TIMER1_INTR_ATTACH(func, arg) \
ets_isr_attach(ETS_FRC_TIMER1_INUM, (func), (void*)(arg))

/* register interrupt handler of GPIO */
#define ETS_GPIO_INTR_ATTACH(func, arg) \
```



```
ets_isr_attach(ETS_GPIO_INUM, (func), (void *)(arg))

/* register interrupt handler of UART */

#define ETS_UART_INTR_ATTACH(func, arg) \
ets_isr_attach(ETS_UART_INUM, (func), (void *)(arg))

/* register interrupt handler of SPI */

#define ETS_SPI_INTR_ATTACH(func, arg) \
ets_isr_attach(ETS_SPI_INUM, (func), (void *)(arg))

/* enable a interrupt */

#define ETS_INTR_ENABLE(inum)    ets_isr_unmask((1<<inum))

/* disable a interrupt */

#define ETS_INTR_DISABLE(inum)   ets_isr_mask((1<<inum))

/* enable SPI interrupt */

#define ETS_SPI_INTR_ENABLE()    ETS_INTR_ENABLE(ETS_SPI_INUM)

/* enable UART interrupt */

#define ETS_UART_INTR_ENABLE()   ETS_INTR_ENABLE(ETS_UART_INUM)

/* disable UART interrupt */

#define ETS_UART_INTR_DISABLE() ETS_INTR_DISABLE(ETS_UART_INUM)

/* enable frc1 timer interrupt */

#define ETS_FRC1_INTR_ENABLE()   ETS_INTR_ENABLE(ETS_FRC_TIMER1_INUM)

/* disable frc1 timer interrupt */

#define ETS_FRC1_INTR_DISABLE() ETS_INTR_DISABLE(ETS_FRC_TIMER1_INUM)

/* enable GPIO interrupt */

#define ETS_GPIO_INTR_ENABLE()   ETS_INTR_ENABLE(ETS_GPIO_INUM)

/* disable GPIO interrupt */

#define ETS_GPIO_INTR_DISABLE() ETS_INTR_DISABLE(ETS_GPIO_INUM)
```



7. Peripheral Related Drivers

7.1. GPIO Related APIs

Please refer to [/user/user_plug.c](#).

Users can apply to Espressif Systems for GPIO document which contains more details.

1. PIN Related Macros

The following macros are used to control the GPIO pins' status.

```
PIN_PULLUP_DIS(PIN_NAME)
    Disable pin pull up

PIN_PULLUP_EN(PIN_NAME)
    Enable pin pull up

PIN_FUNC_SELECT(PIN_NAME, FUNC)
    Select pin function

Example:
PIN_FUNC_SELECT(PERIPH_IO_MUX_MTDX_U, FUNC_GPIO12); // Use MTDX pin as
GPIO12.
```

2. gpio_output_set

Function: set gpio property

Prototype:

```
void gpio_output_set(
    uint32 set_mask,
    uint32 clear_mask,
    uint32 enable_mask,
    uint32 disable_mask
)
```

Input Parameters:

```
uint32 set_mask : set high output; 1:high output; 0:no status change
uint32 clear_mask : set low output; 1:low output; 0:no status change
uint32 enable_mask : enable output bit
uint32 disable_mask : enable input bit
```

Return:

```
null
```

**Example:**

```
gpio_output_set(BIT12, 0, BIT12, 0):
    Set GPIO12 as high-level output;
gpio_output_set(0, BIT12, BIT12, 0):
    Set GPIO12 as low-level output
gpio_output_set(BIT12, BIT13, BIT12|BIT13, 0):
    Set GPIO12 as high-level output, GPIO13 as low-level output.
gpio_output_set(0, 0, 0, BIT12):
    Set GPIO12 as input
```

3. GPIO input and output macro

```
GPIO_OUTPUT_SET(gpio_no, bit_value)
    Set gpio_no as output bit_value, the same as the output example in 5.1.2

GPIO_DIS_OUTPUT(gpio_no)
    Set gpio_no as input, the same as the input example in 5.1.2.

GPIO_INPUT_GET(gpio_no)
    Get the level status of gpio_no.
```

4. GPIO interrupt

```
ETS_GPIO_INTR_ATTACH(func, arg)
    Register GPIO interrupt control function

ETS_GPIO_INTR_DISABLE()
    Disable GPIO interrupt

ETS_GPIO_INTR_ENABLE()
    Enable GPIO interrupt
```

5. gpio_pin_intr_state_set

Function:

set GPIO interrupt state

Prototype:

```
void gpio_pin_intr_state_set(
    uint32 i,
    GPIO_INT_TYPE intr_state
)
```

**Input Parameters:**

```
uint32 i : GPIO pin ID, if you want to set GPIO14, pls use GPIO_ID_PIN(14);  
GPIO_INT_TYPE intr_state : interrupt type as the following:  
typedef enum {  
    GPIO_PIN_INTR_DISABLE = 0,  
    GPIO_PIN_INTR_POSEDGE = 1,  
    GPIO_PIN_INTR_NEGEDGE = 2,  
    GPIO_PIN_INTR_ANYEDGE = 3,  
    GPIO_PIN_INTR_LOLEVEL = 4,  
    GPIO_PIN_INTR_HILEVEL = 5  
} GPIO_INT_TYPE;
```

Return:

```
null
```

6. GPIO Interrupt Handler

Follow the steps below to clear interrupt status in GPIO interrupt processing function:

```
uint32 gpio_status;  
gpio_status = GPIO_REG_READ(GPIO_STATUS_ADDRESS);  
//clear interrupt status  
GPIO_REG_WRITE(GPIO_STATUS_W1TC_ADDRESS, gpio_status);
```

7.2. UART Related APIs

By default, UART0 is debug output interface. In the case of dual UART, UART0 works as data receive and transmit interface, and UART1 as debug output interface. Please make sure all hardware are correctly connected.

Users can apply to Espressif Systems for UART document which contains more details.

1. uart_init

Function:

Initializes baud rates of the two uarts

Prototype:

```
void uart_init(  
    UartBautRate uart0_br,  
    UartBautRate uart1_br  
)
```

**Parameters:**

```
UartBautRate uart0_br : uart0 baud rate  
UartBautRate uart1_br : uart1 baud rate
```

Baud Rates:

```
typedef enum {  
    BIT_RATE_9600 = 9600,  
    BIT_RATE_19200 = 19200,  
    BIT_RATE_38400 = 38400,  
    BIT_RATE_57600 = 57600,  
    BIT_RATE_74880 = 74880,  
    BIT_RATE_115200 = 115200,  
    BIT_RATE_230400 = 230400,  
    BIT_RATE_460800 = 460800,  
    BIT_RATE_921600 = 921600  
} UartBautRate;
```

Return:

```
null
```

2. uart0_tx_buffer

Function:

Sends user-defined data through UART0

Prototype:

```
void uart0_tx_buffer(uint8 *buf, uint16 len)
```

Parameter:

```
uint8 *buf : data to send later  
uint16 len : the length of data to send later
```

Return:

```
null
```

3. uart0_rx_intr_handler

Function:

UART0 interrupt processing function. Users can add the processing of received data in this function. (Receive buffer size: `0x100`; if the received data are more than `0x100`, pls handle them yourselves.)

Prototype:

```
void uart0_rx_intr_handler(void *para)
```

Parameter:

```
void *para : the pointer pointing to RcvMsgBuff structure
```



Return:
null

7.3. I2C Master Related APIs

Users can apply to Espressif Systems for I2C document which contains more details.

1. i2c_master_gpio_init

Function:
Set GPIO in I2C master mode

Prototype:
`void i2c_master_gpio_init (void)`

Input Parameters:
null

Return:
null

2. i2c_master_init

Function:
Initialize I2C

Prototype:
`void i2c_master_init(void)`

Input Parameters:
null

Return:
null

3. i2c_master_start

Function: configures I2C to start sending data

Prototype:
`void i2c_master_start(void)`

Input Parameters:
null

Return:
null



4. i2c_master_stop

Function:

configures I2C to stop sending data

Prototype:

```
void i2c_master_stop(void)
```

Input Parameters:

null

Return:

null

5. i2c_master_send_ack

Function:

Sends I2C ACK

Prototype:

```
void i2c_master_send_ack (void)
```

Input Parameters:

null

Return:

null

6. i2c_master_send_nack

Function:

Sends I2C NACK

Prototype:

```
void i2c_master_send_nack (void)
```

Input Parameters:

null

Return:

null

7. i2c_master_checkAck

Function:

Checks ACK from slave

Prototype:

```
bool i2c_master_checkAck (void)
```

**Input Parameters:**`null`**Return:**

true: get I2C slave ACK
false: get I2C slave NACK

8. i2c_master_readByte

Function:

Read one byte from I2C slave

Prototype:`uint8 i2c_master_readByte (void)`**Input Parameters:**`null`**Return:**`uint8` : the value that was read

9. i2c_master_writeByte

Function:

Write one byte to slave

Prototype:`void i2c_master_writeByte (uint8 wrdata)`**Input Parameters:**`uint8 wrdata` : data to write**Return:**`null`



7.4. PWM Related

Herein only introduces the PWM related APIs in `pwm.h`. Users can apply to Espressif Systems for PWM document which contains more details.

PWM APIs can not be called when APIs in `hw_timer.c` are using, because they are using the same hardware timer.

1. `pwm_init`

Function:

Initialize PWM function, including GPIO selection, period and duty cycle.

Note:

This API can be called only once.

Prototype:

```
void pwm_init(  
    uint32 period,  
    uint8 *duty,  
    uint32 pwm_channel_num,  
    uint32 (*pin_info_list)[3])
```

Parameter:

```
uint32 period : PWM period  
uint8 *duty : duty cycle of each output  
uint32 pwm_channel_num: PWM channel number  
uint32 (*pin_info_list)[3]: GPIO parameter of PWM channel, it is a pointer  
of n * 3 array which defines GPIO register, IO reuse of corresponding PIN  
and GPIO number.
```

Return:

null

Example:

```
uint32 io_info[][] =  
{{{PWM_0_OUT_IO_MUX,PWM_0_OUT_IO_FUNC,PWM_0_OUT_IO_NUM},  
{PWM_1_OUT_IO_MUX,PWM_1_OUT_IO_FUNC,PWM_1_OUT_IO_NUM},  
{PWM_2_OUT_IO_MUX,PWM_2_OUT_IO_FUNC,PWM_2_OUT_IO_NUM}}};  
pwm_init(light_param.pwm_period, light_param.pwm_duty, 3, io_info);
```



2. pwm_start

Function:

Starts PWM. This function needs to be called after PWM config is changed.

Prototype:

```
void pwm_start (void)
```

Parameter:

null

Return:

null

3. pwm_set_duty

Function:

Sets duty cycle of a PWM output. Set the time that high-level single will last, duty depends on period, the maximum value can be Period * 1000 /45. For example, 1KHz PWM, duty range is 0 ~ 22222

Note:

After set configuration, `pwm_start` need to be called to take effect.

Prototype:

```
void pwm_set_duty(uint32 duty, uint8 channel)
```

Input Parameters:

`uint32 duty` : the time that high-level single will last, duty cycle will be $(duty*45)/ (period*1000)$
`uint8 channel` : PWM channel, depends on how many PWM channels is used, in `IOT_Demo` it depends on `#define PWM_CHANNEL`

Return:

null

4. pwm_get_duty

Function:

Gets duty cycle of PWM output, duty cycle will be $(duty*45)/ (period*1000)$

Prototype:

```
uint8 pwm_get_duty(uint8 channel)
```

Input Parameters:

`uint8 channel` : PWM channel, depends on how many PWM channels is used, in `IOT_Demo` it depends on `#define PWM_CHANNEL`

**Return:**

```
uint8 : duty cycle of PWM output
```

5. pwm_set_period

Function:

Sets PWM period, unit: us. For example, for 1KHz PWM, period is 1000 us

Note:

After set configuration, `pwm_start` need to be called to take effect.

Prototype:

```
void pwm_set_period(uint32 period)
```

Input Parameters:

```
uint32 period : PWM period, unit: us
```

Return:

```
null
```

6. pwm_get_period

Function:

Gets PWM period.

Prototype:

```
uint32 pwm_get_period(void)
```

Parameter:

```
null
```

Return:

PWM period, unit: us.

7. get_pwm_version

Function:

Get version information of PWM.

Prototype:

```
uint32 get_pwm_version(void)
```

Parameter:

```
none
```

Return:

PWM version



8. Appendix

8.1. ESPCONN Programming

1. TCP Client Mode

Notes

- ESP8266, working in Station mode, will start client connection when given an IP address.
- ESP8266, working in soft-AP mode, will start client connection when the devices which are connected to ESP8266 are given an IP address.

Steps

- Initialize `espconn` parameters according to protocols.
- Register connect callback function, and register reconnect callback function.
 - ▶ (Call `espconn_regist_connectcb` and `espconn_regist_reconcb`)
- Call `espconn_connect` function and set up the connection with TCP Server.
- Registered connected callback function will be called after successful connection, which will register the corresponding callback function. Recommend to register disconnect callback function.
 - ▶ (Call `espconn_regist_recvcb`, `espconn_regist_sentcb` and `espconn_regist_disconcb` in connected callback)
- When using receive callback function or sent callback function to run disconnect, it is recommended to set a time delay to make sure that the all the firmware functions are completed.

2. TCP Server Mode

Notes

- If ESP8266 is in Station mode, it will start server listening when given an IP address.
- If ESP8266 is in soft-AP mode, it will start server listening.

Steps

- Initialize `espconn` parameters according to protocols.
- Register connect callback and reconnect callback function.
 - ▶ (Call `espconn_regist_connectcb` and `espconn_regist_reconcb`)
- Call `espconn_accept` function to listen to the connection with host.



- Registered connect function will be called after successful connection, which will register corresponding callback function.
 - (Call `espconn_regist_recvcb`, `espconn_regist_sentcb` and `espconn_regist_disconcb` in connected callback)

3. espconn callback

Register Function	Callback	Description
<code>espconn_regist_connectcb</code>	<code>espconn_connect_callback</code>	TCP connected successfully
<code>espconn_regist_reconcb</code>	<code>espconn_reconnect_callback</code>	Error occur, TCP disconnected
<code>espconn_regist_sentcb</code>	<code>espconn_sent_callback</code>	Sent TCP or UDP data
<code>espconn_regist_recvcb</code>	<code>espconn_recv_callback</code>	Received TCP or UDP data
<code>espconn_regist_write_finish</code>	<code>espconn_write_finish_callback</code>	Write data into TCP-send-buffer
<code>espconn_regist_disconcb</code>	<code>espconn_disconnect_callback</code>	TCP disconnected successfully

Notice:

- Parameter `arg` of callback is the pointer corresponding structure `espconn`. This pointer may be different in different callbacks, please don't use this pointer directly to distinguish one from another in multiple connections, use `remote_ip` and `remote_port` in `espconn` instead.
- If `espconn_connect` (or `espconn_secure_connect`) fail, returns non-0 value, there is no connection, so it won't enter any `espconn` callback.

8.2. RTC APIs Example

Demo code below shows how to get RTC time and to read and write to RTC memory.

```
#include "ets_sys.h"
#include "osapi.h"
#include "user_interface.h"

os_timer_t rtc_test_t;
#define RTC_MAGIC 0x55aaaa55

typedef struct {
    uint64 time_acc;
    uint32 magic ;
    uint32 time_base;
}RTC_TIMER_DEMO;
```



```
void rtc_count()
{
    RTC_TIMER_DEMO rtc_time;
    static uint8 cnt = 0;
    system_rtc_mem_read(64, &rtc_time, sizeof(rtc_time));

    if(rtc_time.magic!=RTC_MAGIC){
        os_printf("rtc time init...\r\n");
        rtc_time.magic = RTC_MAGIC;
        rtc_time.time_acc= 0;
        rtc_time.time_base = system_get_rtc_time();
        os_printf("time base : %d \r\n",rtc_time.time_base);
    }

    os_printf("=====\\r\\n");
    os_printf("RTC time test : \\r\\n");

    uint32 rtc_t1,rtc_t2;
    uint32 st1,st2;
    uint32 cal1, cal2;

    rtc_t1 = system_get_rtc_time();
    st1 = system_get_time();

    cal1 = system_rtc_clock_cali_proc();
    os_delay_us(300);

    st2 = system_get_time();
    rtc_t2 = system_get_rtc_time();

    cal2 = system_rtc_clock_cali_proc();
    os_printf(" rtc_t2-t1 : %d \r\n",rtc_t2 rtc_t1);
    os_printf(" st2-t2 : %d \r\n",st2-st1);
    os_printf("cal 1 : %d.%d \r\n", ((cal1*1000)>>12)/1000,
    ((cal1*1000)>>12)%1000 );
    os_printf("cal 2 : %d.%d \r\n",((cal2*1000)>>12)/1000,
    ((cal2*1000)>>12)%1000 );
    os_printf("=====\\r\\n\\r\\n");
```



```
    rtc_time.time_acc += ( ((uint64)(rtc_t2 - rtc_time.time_base)) *  
    ( (uint64)((cal2*1000)>>12)) ) ;  
    os_printf("rtc time acc : %lld \r\n",rtc_time.time_acc);  
    os_printf("power on time : %lld us\r\n", rtc_time.time_acc/1000);  
    os_printf("power on time : %lld.%02lld S\r\n", (rtc_time.time_acc/  
    100000000)/100, (rtc_time.time_acc/10000000)%100);  
  
    rtc_time.time_base = rtc_t2;  
    system_rtc_mem_write(64, &rtc_time, sizeof(rtc_time));  
    os_printf("-----\r\n");  
  
    if(5== (cnt++)){  
        os_printf("system restart\r\n");  
        system_restart();  
    }else{  
        os_printf("continue ... \r\n");  
    }  
}  
  
void user_init(void)  
{  
    rtc_count();  
    os_printf("SDK version:%s\n", system_get_sdk_version());  
  
    os_timer_disarm(&rtc_test_t);  
    os_timer_setfn(&rtc_test_t,rtc_count,NULL);  
    os_timer_arm(&rtc_test_t,10000,1);  
}
```

8.3. Sniffer Structure Introduction

ESP8266 can enter promiscuous mode (sniffer) and capture IEEE 802.11 packets in the air.

The following HT20 packets are support:

- 802.11b
- 802.11g
- 802.11n (from MCS0 to MCS7)



- AMPDU types of packets

The following are not supported:

- HT40
- LDPC

Although ESP8266 can not completely decipher these kinds of IEEE80211 packets completely, it can still obtain the length of these special packets.

In summary, while in sniffer mode, ESP8266 can either capture completely the packets or obtain the length of the packet:

- Packets that ESP8266 can decipher completely; ESP8266 returns with the
 - ▶ MAC address of the both side of communication and encryption type and
 - ▶ the length of entire packet.
- Packets that ESP8266 can only partial decipher; ESP8266 returns with
 - ▶ the length of packet.

Structure `RxControl` and `sniffer_buf` are used to represent these two kinds of packets. Structure `sniffer_buf` contains structure `RxControl`.

```
struct RxControl {  
    signed rssi:8;           // signal intensity of packet  
    unsigned rate:4;  
    unsigned is_group:1;  
    unsigned:1;  
    unsigned sig_mode:2;     // 0:is 11n packet; 1:is not 11n packet;  
    unsigned legacy_length:12; // if not 11n packet, shows length of packet.  
    unsigned damatch0:1;  
    unsigned damatch1:1;  
    unsigned bssidmatch0:1;  
    unsigned bssidmatch1:1;  
    unsigned MCS:7;          // if is 11n packet, shows the modulation  
                           // and code used (range from 0 to 76)  
    unsigned CWB:1;          // if is 11n packet, shows if is HT40 packet or not  
    unsigned HT_length:16; // if is 11n packet, shows length of packet.  
    unsigned Smoothing:1;  
    unsigned Not_Sounding:1;  
    unsigned:1;  
    unsigned Aggregation:1;
```



```
    unsigned STBC:2;
    unsigned FEC_CODING:1; // if is 11n packet, shows if is LDPC packet or not.
    unsigned SGI:1;
    unsigned rxend_state:8;
    unsigned ampdu_cnt:8;
    unsigned channel:4; //which channel this packet in.
    unsigned:12;
};

struct LenSeq{
    u16 len; // length of packet
    u16 seq; // serial number of packet, the high 12bits are serial number,
              // low 14 bits are Fragment number (usually be 0)
    u8 addr3[6]; // the third address in packet
};

struct sniffer_buf{
    struct RxControl rx_ctrl;
    u8 buf[36 ]; // head of ieee80211 packet
    u16 cnt; // number count of packet
    struct LenSeq lenseq[1]; //length of packet
};

struct sniffer_buf2{
    struct RxControl rx_ctrl;
    u8 buf[112];
    u16 cnt;
    u16 len; //length of packet
};
```

Callback `wifi_promiscuous_rx` has two parameters (`buf` and `len`). `len` means the length of `buf`, it can be: `len = 128`, `len = X * 10`, `len = 12`:

Case of LEN == 128

- `buf` contains structure `sniffer_buf2`: it is the management packet, it has 112 bytes data.
- `sniffer_buf2.cnt` is 1.
- `sniffer_buf2.len` is the length of packet.



Case of LEN == X * 10

- buf contains structure `sniffer_buf`: this structure is reliable, data packets represented by it has been verified by CRC.
- `sniffer_buf.cnt` means the count of packets in buf. The value of len depends on `sniffer_buf.cnt`.
 - `sniffer_buf.cnt==0`, invalid buf; otherwise, `len = 50 + cnt * 10`
- `sniffer_buf.buf` contains the first 36 bytes of ieee80211 packet. Starting from `sniffer_buf.lenseq[0]`, each structure `lenseq` represent a length information of packet. `lenseq[0]` represents the length of first packet. If there are two packets where (`sniffer_buf.cnt == 2`), `lenseq[1]` represents the length of second packet.
- If `sniffer_buf.cnt > 1`, it is a AMPDU packet, head of each MPDU packets are similar, so we only provide the length of each packet (from head of MAC packet to FCS)
- This structure contains: length of packet, MAC address of both sides of communication, length of the head of packet.


Case of LEN == 12

- buf contains structure `RxControl`; but this structure is not reliable, we can not get neither MAC address of both sides of communication nor length of the head of packet.
- For AMPDU packet, we can not get the count of packets or the length of packet.
- This structure contains: length of packet, `rssi` and `FEC_CODING`.
- `RSSI` and `FEC_CODING` are used to guess if the packets are sent from same device.

Summary

We should not take too long to process the packets. Otherwise, other packets may be lost.

The diagram below shows the format of a ieee80211 packet:



- The first 24 bytes of MAC Header of data packet are needed:
 - `Address 4` field depends on `FromDS` and `ToDS` which is in `Frame Control`;



- `QoS Control` field depends on `Subtype` which is in `Frame Control`;
- `HT Control` field depends on `Order Field` which is in `Frame Control`;
- More details are found in IEEE Std 802.11-2012.
- For WEP packets, MAC Header is followed by 4 bytes IV and before FCS there are 4 bytes ICV.
- For TKIP packet, MAC Header is followed by 4 bytes IV and 4 bytes EIV, and before FCS there are 8 bytes MIC and 4 bytes ICV.
- For CCMP packet, MAC Header is followed by 8 bytes CCMP header, and before FCS there are 8 bytes MIC.

8.4. ESP8266 soft-AP and station channel configuration

Even though ESP8266 can be in soft-AP + station mode, it actually has only one hardware channel.

So in soft-AP + station mode, ESP8266 soft-AP will adjust its channel configuration to be as same as ESP8266 station.

This limitation may cause some inconvenience in softAP + station mode users need to pay attention, for example:

Case 1.

- (1) If user connect ESP8266 station to a router(e.g. router is in channel 6)
- (2) Then set ESP8266 softAP by `wifi_softap_set_config`
- (3) The API may return true, but channel will always be channel 6. Because we have only one hardware channel.

Case 2.

- (1) If user set ESP8266 softAP a channel number(e.g. channel 5) by `wifi_softap_set_config`
- (2) Some stations connected to ESP8266 softAP.
- (3) Then connect ESP8266 station to a router of which channel number is different (e.g. channel 6).
- (4) ESP8266 softAP has to adjust its channel to be as same as ESP8266 station , in this case, is channel 6.
- (5) So the stations that connected to ESP8266 softAP in step 2 will be disconnected because of the channel change.